
# ENVIRONMENTAL DUSTTRAK™ AEROSOL MONITOR CONFIGURATOR

WHAT SIZE FRACTION DO YOU WANT TO MEASURE, AND WILL THE INSTRUMENT BE OPERATING IN TEMPS BELOW 32°F (0°C)?





# ENVIRONMENTAL DUSTTRAK™ AEROSOL MONITOR FAQs

#### Lowest operating temp?

32° to 122°F (0° to 50°C); -4° to 122°F (-20° to 50°C) with enclosure heater

#### **Battery run time**

24 hrs on 1 battery, 48 hrs on 2 batteries. With Heated Inlet: 15 hr on 1 battery, 30 hrs on 2 batteries

### Who needs a heated inlet sample conditioner?

People measuring outdoor dust in humid environments above 50% Rh and parts of the world with seasonal temperature/humidity swings.

### What does heated inlet sample conditioner do?

Conditions the sampled aerosol to improve measurement accuracy by minimizing the effects of humidity when environments are consistently >50% Rh.

## What setting do I set the heated inlet sample conditioner to?

The heated inlet sample conditioner is designed to reduce the sampled air to 30%, 40% or 50% Relative Humidity.

- + In the US, the EPA requires humidity control to 30-40% for PM10 particle sampling, and 35% for PM2.5 particle sampling.
- + In the UK, EN12341 requires humidity control to 50%  $\pm$  5% for PM10 particulates, and 30-40% for PM2.5 particulates.
- $\pm$  The NIOSH Analytical Method 0600 for Particulates, not otherwise classified, Respirable, specifies the sample filter media be equilibrated in an environmental chamber at 20°  $\pm$  1° C and 50  $\pm$  5% Relative Humidity.

US	
Outdoor environmental sampling for PM2.5	35% Rh
Outdoor environmental sampling for PM10	30-40% Rh
Occupational Exposure sampling for respirable dust	50% Rh

UK	
Outdoor environmental sampling for PM2.5	30-40% Rh
Outdoor environmental sampling PM10	50% Rh

## How does the heated inlet sample conditioner work?

A humidity/temperature sensor is used to measure the environment and turn the heater elements on and off based on a dew point algorithm. The incoming air is heated to reduce the humidity to the selected level.

# What does the auto zero do?

Reduces instrument drift by periodically stopping sampling and adjusting the instrument response to a situation with zero particles in the optics.

# What do you mean by photometer drift or instrument drift?

Drift is a change in readings that is not consistent with the present dust levels. Drift occurs over time due to contamination of the optics and can also be caused by temperature changes.

#### How much does the Environmental DustTrak Monitor weigh?

Basic Package	lbs	kg
Env. DustTrak	5.3	2.4
Enclosure	19.6	8.9
Netronix Node Kit	0.81	0.38
Omni- directional Inlet	2.2	1
Impactor	0.23	0.105
Power Supply	1.7	0.77
Total	29.84	13.555

Loaded Package	lbs	kg
Env. DustTrak	5.3	2.4
Enclosure	19.6	8.9
Netronix Node Kit with Extender	1	0.45
Omni- directional Inlet	2.2	1
Impactor	0.23	0.105
Solar Shield	2	0.9
Handle Kit	0.6	0.27
Pole Mount Kit	6.7	3.04
Heated Inlet Sample Conditioner	2	0.9
Enclosure Heater Kit	3.4	1.54
Total	43.03	19.5

Battery Package	lbs	kg
Env. DustTrak	5.3	2.4
Enclosure	19.6	8.9
Netronix Node Kit with Extender	1	0.45
Omni- directional Inlet	2.2	1
Impactor	0.23	0.105
Solar Shield	2	0.9
Handle Kit	0.6	0.27
Pole Mount Kit	6.7	3.04
Heated Inlet Sample Conditioner	2	0.9
Battery Kit	30	13.6
Total	69.63	31.565

#### **Environmental DustTrak Monitor Impactor Maintenance Interval**

Average dust concentration (mg/m³)	Impactor maintenance interval
0.035	42 days
0.050	30 days
0.100	16 days
0.150	10 days
0.250	6 days
0.440	4 days

## Environmental DustTrak Monitor Power Budget

	•
	Estimated Power (W)
DustTrak	8
Thiamis Module	1
Heated Inlet Sample Conditioner	13
Weather Station	24
Enclosure Heater	1041
Total	150

<sup>1</sup> Note: When the enclosure heater turns on, it may draw up to 340W of inrush power.

