

Guide for Custom Field Data for TSI Link™ for Respiratory Protection



Background

Ensuring clarity about what fields represent and how they are displayed in the system helps to ensure you import the data properly and understand what is shown in the Portal.

This guide provides links to an examples file, to an import template and provides a data dictionary. This can help you understand the Custom Field Data for TSI Link™ for Respiratory Protection.

Links to Resources

[Custom Fields Template](#)

[Custom Field Import Example](#)

[TSI Link for Respiratory Protection API documentation](#) (Login Required)

Data Dictionary

Custom Fields

Field Name	TSI Link field Name *	Required	Field Type	Example	Notes
row	The custom Field ID, where on the list it is for the account	Yes	toIndex	2	0, 1 = company and location, rest are 2 to 5
labelName	Custom Field Label	No	toText(20)	Department	Up to 20 characters
required	Required	No	toNumber	1	Is the custom field required? A flag in UI
enabled	<i>is the custom field editable</i>	No	toNumber	1	Enabled = 1, deleted = 0, deleting clears the custom field from the people records, and resets the data label, should reflect Active Field
active	<i>if it is a currently active field and available in the table</i>	No	toNumber	1	0 = row is not being used, deleted; 1 = row is being used. Always true for company and location
combo	<i>type of custom field</i>	No	toNumber	0	when = 0, is a drop down box, when 1 = text field with optional combo box

Field Name	TSI Link field Name *	Required	Field Type	Example	Notes
option0	<i>Option 0 for a given Custom Field with type = Dropdown</i>	No	toText(25)	Engineering	unique per Custom field per Dataset per account , null if not used
option1	<i>Option 1 for a given Custom Field with type = Dropdown</i>	No	toText(25)	Manufacturing Plant 1	unique per Custom field per Dataset per account , null if not used
option2	<i>Option 2 for a given Custom Field with type = Dropdown</i>	No	toText(25)	Manufacturing Plant 2	unique per Custom field per Dataset per account , null if not used
option3	<i>Option 3 for a given Custom Field with type = Dropdown</i>	No	toText(25)	Marketing	unique per Custom field per Dataset per account , null if not used
option4	<i>Option 4 for a given Custom Field with type = Dropdown</i>	No	toText(25)	Research & Dev	unique per Custom field per Dataset per account , null if not used
option5	<i>Option 5 for a given Custom Field with type = Dropdown</i>	No	toText(25)	Sales	unique per Custom field per Dataset per account , null if not used
option6	<i>Option 6 for a given Custom Field with type = Dropdown</i>	No	toText(25)	Security	unique per Custom field per Dataset per account , null if not used
option7	<i>Option 7 for a given Custom Field with type = Dropdown</i>	No	toText(25)		unique per Custom field per Dataset per account , null if not used
option8	<i>Option 8 for a given Custom Field with type = Dropdown</i>	No	toText(25)		unique per Custom field per Dataset per account , null if not used
option9	<i>Option 9 for a given Custom Field with type = Dropdown</i>	No	toText(25)		unique per Custom field per Dataset per account , null if not used
autoComplete	Auto Complete	No	toBoolean	0	toBoolean: "yes", "true", 1="true", "no", "false", 0 = false
allowFiltering	Allow Program Status Filtering	No	toBoolean	1	toBoolean: "yes", "true", 1="true", "no", "false", 0 = false

Note * *Italics = not a specific field on the TSI Link website, so the use is described*



kenelec
scientific

Distributed by:

Kenelec Scientific Pty Ltd
1300 73 22 33
sales@kenelec.com.au
www.kenelec.com.au



Knowledge Beyond Measure.

TSI Incorporated – Visit our website www.tsi.com for more information.

USA	Tel: +1 800 680 1220	India	Tel: +91 80 67877200
UK	Tel: +44 149 4 459200	China	Tel: +86 10 8251 6588
France	Tel: +33 4 91 11 87 64	Singapore	Tel: +65 6595 6388
Germany	Tel: +49 241 523030		

5003308 Rev A

©2025 TSI Incorporated

Printed in U.S.A

TSI and the TSI logo are registered trademarks of TSI Incorporated in the United States and may be protected under other country's trademark registrations.



5003308