

## QUICK REFERENCE GUIDE

### Mounting Bracket for Humidity Module HMM100



- Metal backplate and a plastic lid for a single HMM100 module
- Can be installed on a DIN rail

## GENERAL

The mounting bracket for HMM100 humidity modules provides convenient installation and handling protection for the HMM100. Note that the bracket does not provide IP rated protection.

The mounting bracket includes the following parts:

- metal mounting bracket with four screws for attaching the module
- plastic lid with two screws
- screws and clamps for holding the probe cable and the power/signal cable
- Abiko connector (4.8mm push-on male terminal) to be used with unshielded power/signal cables
- DIN rail clip and screw



Figure 1 Mounting Bracket Parts

## INSTALLATION

1. Attach the module to the bracket with four screws; see Figure 2.



Figure 2 Module Mounted in the Bracket

2. Connect the power/signal cable to the screw terminals. Refer to the HMM100 User's Guide for wiring instructions.
3. Attach the probe cable and the power/signal cable to the right side of the bracket using the screws and metal clips. See Figure 3 for the suggested placement.




Figure 3 Connecting Cables

- [illegible]

Visit our Internet pages at