



# TR-525 Rain Gauge With Hobo™ Datalogger



## TR-525 Series Rain Gauge with HOBO™ Datalogger

Texas Electronic's TR-525 rain gauges, (TR-525 Inches, Metric, & USW) can be equipped with a HOBO™ Event Logger. The HOBO™ is a single channel battery powered datalogger ideal for supporting remote unattended rainfall data stations. The unit is 4.25" x 3.50" x 1.75" and weighs 3.3 ounces. It is housed in a weatherproof case and a lithium battery will provide up to one year of continuous use. The data storage capacity is 2000 events (20 inches of rainfall when used with a 0.01"/tip rain gauge). The software for the HOBO™ Event Logger is called BOXCAR™ and will provide a tabular printout of date/time stamped accumulated rainfall as the data can be exported to spreadsheets for further analysis.

*HOBO and BOXCAR are registered trademarks of Onset Computers.*



### **Texas Electronics, Inc.**

P.O. Box 7225 • Dallas, Texas 75209  
800-424-5651 • Fax: 214-631-4218  
E-mail: [info@texaselectronics.com](mailto:info@texaselectronics.com)