



WS755 Improved Stormwater/Wastewater Sampler



- Ideal for wastewater, industrial, and environmental sampling
- Quick disconnect pickup hoses conveniently stored inside the enclosure for easy transport
- Simple to operate – no programming required
- Heavy duty wheels and retractable handle built in
- Timed and external flow pulsed composite samples
- Enclosed battery compartment and smart battery charger to improve battery life

Description

The WS755 improved two-bottle samplers combine all the features needed to meet a wide variety of water sampling requirements, including those for stormwater, industrial discharge, water/wastewater treatment, waste collection systems, and rivers.

Improved Water Sampler Enclosure

The WS755's rugged rainproof enclosure can be padlocked and/or chained to prevent tampering. The case can be easily hidden or camouflaged to prevent vandalism. They are lightweight enough that even with a full sample bottle they can be suspended, from the over-molded handle on top, in a manhole for wastewater or stormwater sampling. The enclosure features heavy duty polyurethane wheels and a retractable extension handle for easy transport. The pickup hoses come with quick disconnect fittings which allows them to be disconnected from the WS755 and conveniently stored inside the enclosure when being moved or when not in use.

Sampler Power

The WS755's 5 AH rechargeable battery will power the sampler for several months or several sampling events. The sealed gel-cell battery and BC100 smart charge controller are contained in a separate battery box inside the unit's main enclosure to isolate and protect electrical connections. The included smart charger prevents overcharging and greatly extends battery life over other charging methods. Optional AC and solar panel charging options are available.

Specifications

Operating Temperature: 32° to +158°F (0° to +70°C)

Materials:

Enclosure: Expanded UV protected PVC

Bottle: Two 1 gallon polyethylene

Pickup Hose: 15' reinforced PVC 1/4" ID polyethylene flexible tubing section with intake strainer

Pump Tubing: Norprene 1/4" ID, 7/16" OD

Sample Pump

Flow Rate: 1000 ml per minute at a 4 foot head

Type: Peristaltic

Maximum Lift: ~20 ft (6 m)

Battery Life: One Pump running continuously: ~1 hour

Two Pumps running continuously: ~ ½ hour

Standby: 3 months while still retaining enough power to run the pump to capacity

Start Delay: 16 time settings from 0 to 12 hours

Composite Interval: 15 time settings from 5 min. to 12 hours plus an External Trigger mode setting

Sample Size: 15 composite sample sizes from 50 ml to 2 liters plus a Full Bottle discrete setting (Approximate sizes at 4 foot head)

External Trigger Input: 250 mS minimum pulse width
Switch closure or 4-24 VDC

Pulse Output: 5 VDC one-second pulse
1000 ohm output impedance

Bottle Switch Input: Switch closure Input
Floating read switch in bottle

Rain and Water Sensors: Optional moisture sensors or switch closure inputs

Internal Fuse: 10A Slow-Blow

Size of unit: 22x18x10 inch (56x45.7x25.4 cm) (HxWxD)

Weight: 30 lb (13.6 kg) (Shipping Weight 32 lb (14.5 kg))

Options and Accessories

WS755 Improved Stormwater/Wastewater Sampler

WSSWK Stormwater Kit

Includes CA0400 Rain Sensor, CA0500 Flow Sensor and RG333 Auto-drain Rain Gauge

For other parts and options please visit our website.



In the U.S. call toll free
at 1-800-876-1172
International: 916-638-3429
Fax: 916-638-3270
Email: globalw@globalw.com

Visit our online catalog at:
www.globalw.com
Our Address:
11390 Amalgam Way
Gold River, CA 95670

Contact
Global Water
for all your
instrumentation
needs:

Water Level

Water Flow

Water Samplers

Water Quality

Weather

Remote Monitoring

Control