

## Outdoor Carbon Dioxide Measurements for Demand Controlled Ventilation



*The outdoor CO<sub>2</sub> level serves as a baseline for comparison to indoor CO<sub>2</sub> concentration. If the outdoor CO<sub>2</sub> concentration level is 500 ppm, it is rarely lower indoors. Selecting a stable outdoor CO<sub>2</sub> instrument is crucial for monitoring outdoor levels.*

Demand controlled ventilation (DCV) helps to maintain good indoor air quality while optimizing energy consumption. In a typical set-up only indoor CO<sub>2</sub> levels are measured. Ventilation controls are operated based on the assumed outdoor CO<sub>2</sub> level of 400 ppm. However, locally elevated CO<sub>2</sub> levels occur due to CO<sub>2</sub> emissions from transportation, energy production and industrial manufacturing.

Ventilation guidelines, such as ASHRAE, recommend indoor CO<sub>2</sub> levels not to exceed the surrounding

outdoor concentration by 600 ppm. Also, LEED guidelines suggest providing an alarm when the indoor CO<sub>2</sub> level exceeds the outdoor level by 530 ppm, or 1,000 ppm absolute. Reliable correlation between indoor and outdoor CO<sub>2</sub> levels can only be achieved by measuring both.


### Measuring CO<sub>2</sub> Outdoors

Knowing outdoor CO<sub>2</sub> levels helps when assessing indoor conditions. During periods when the outdoor CO<sub>2</sub> level exceeds 400 ppm the space

may be over-ventilated. In order to truly optimize energy consumption, outdoor CO<sub>2</sub> concentration should be measured. The real time differential between indoor and outdoor CO<sub>2</sub> concentration can be used as a control parameter.

As there are large diurnal and seasonal variations in outdoor temperature, the outdoor CO<sub>2</sub> instrument should automatically compensate for temperature variations.

*Outdoor CO<sub>2</sub> sensors need to operate in varying conditions. They have to tolerate rain, hail, snow, solar radiation, dirt and dust, as well as temperature extremes between -40 and +60 °C (-40 ... +140 °F).*



*Radiation shield DTR250A (right) with GMP252 probe*

### Vaisala Radiation Shield DTR250 Series:

- GMP252 inside the radiation shield is an ideal solution for dynamically measuring outdoor CO<sub>2</sub> levels
- Meets the specifications of Section 6.2.7 in the ASHRAE Green Buildings Standard 62.1
- Two options: DTR250 for support bars and DTR250A for pole masts

### GMP252 probe features:

- Wide operating temperature range of -40 ... +60 °C (-40 ... +140 °F)
- Integrated temperature sensor for continuous compensation
- Sensor head heated to prevent condensation
- Traceable calibration (certificate included)



*GMP343 for outdoor measurements*

### Vaisala CARBOCAP® Carbon Dioxide Probe GMP343 for Outdoor Measurements:

Vaisala CARBOCAP® Carbon Dioxide Probe GMP343 has been specially designed for high accuracy outdoor measurements:

- Accuracy of  $\pm(3 \text{ ppm} + 1 \% \text{ of reading})$  at 25 °C (77 °F)
- IP65/IP66 housing classification for harsh environments
- Operating temperature range -40 ... +60 °C (-40 ... +140 °F)
- Low maintenance need due to highly stable CARBOCAP® sensor with built-in reference measurement
- Automatic compensation of CO<sub>2</sub> readings for temperature variations
- Possibility to compensate for pressure (site elevation)

# VAISALA



Please contact us at  
[www.vaisala.com/requestinfo](http://www.vaisala.com/requestinfo)

Distributed by:  
Kenelec Scientific Pty Ltd  
1300 73 22 33  
[sales@kenelec.com.au](mailto:sales@kenelec.com.au)  
[www.kenelec.com.au](http://www.kenelec.com.au)



Scan the code for  
more information

Ref. B211381EN-B ©Vaisala 2018

This material is subject to copyright protection, with all copyrights retained by Vaisala and its individual partners. All rights reserved. Any logos and/or product names are trademarks of Vaisala or its individual partners. The reproduction, transfer, distribution or storage of information contained in this brochure in any form without the prior written consent of Vaisala is strictly prohibited. All specifications — technical included — are subject to change without notice.