

# MITA MASK ADAPTER KIT MODEL 8125-02

---

INSTRUCTIONS GUIDE



APPLICABLE MASK MODELS:  
M50 AND C50

# Included Accessories

<p><b>Drink Tube (DT) Valve Adapter</b></p> <ul style="list-style-type: none"><li>➤ Installed on mask during <b>DT Flow</b> test</li></ul>	
<p><b>Mask Filter Plug</b> (Qty. 2)</p> <ul style="list-style-type: none"><li>➤ Installed on mask during <b>Protection Factor</b> test</li></ul>	
<p><b>Exhalation Valve (EV) Adapter</b> (for M50 and C50 masks)</p> <ul style="list-style-type: none"><li>➤ Connect to Mask Exhalation Valve during <b>EV Leak</b> test</li></ul>	
<p><b>EV Self Check Zero Fixture</b></p> <ul style="list-style-type: none"><li>➤ Connect to EV Adapter, during the <b>EV Leak Zero Test</b> option of the Self Checks procedure</li></ul>	

# Components Installed on Masks



Example of M50 and C50 with DT Valve Adapter



Example of M50 and C50 with Mask Filter Plug



**Example of M50 and C50 with EV Adapter**



**Example of M50 and C50 with all adapters**



UNDERSTANDING, ACCELERATED

**TSI Incorporated** – Visit our website [www.tsi.com](http://www.tsi.com) for more information.

**USA**      Tel: +1 800 874 2811  
**UK**        Tel: +44 149 4 459200  
**France**   Tel: +33 4 91 11 87 64  
**Germany** Tel: +49 241 523030

**India**        Tel: +91 80 67877200  
**China**      Tel: +86 10 8219 7688  
**Singapore** Tel: +65 6595 6388