



® Knowledge Beyond Measure.

SidePak™ Personal Aerosol Monitor

Models AM520 and AM520i



The SidePak™ AM520 and AM520i Personal Aerosol Monitors are compact, battery-powered, data-logging photometers that provide real-time aerosol mass concentration measurements in a worker's breathing zone.

These monitors are the perfect solution for real-time, personal aerosol sampling in a variety of workplace environments, including but not limited to general industry, foundries, construction sites, pre-cast concrete and cement, chemical plants, refineries, petrochemical, power and utilities, transportation, aerospace, maritime, confined spaces and mining. For monitoring in flammable and explosive environments—Model AM520i is the smallest intrinsically safe real-time photometric personal exposure monitor currently available on the global market.

Newly designed inlet conditioners increase the mass concentration capability and provide size fraction cut points for PM10, Respirable (PM4), PM5 (China Respirable), PM2.5, PM1 and 0.8 μ m Diesel Particulate Matter (DPM).

New Features and Benefits

- Dual display and logging of mass concentration and response concentration on one screen
- Stores up to 10 custom calibration factors on the instrument for different applications
- **TrakPro™ v5 Data Analysis Software** updated with:
 - Custom calibration factor calculator to simplify calibration factor process
 - Continued ability to name custom calibration factors and upload them to the instrument
 - Enhanced alarm features to include response concentration alarm value

Features and Benefits

- Real-time mass concentration and secondary response concentration measurement and data logging for "in-the-field" data analysis of multiple aerosols
- Push button menu operation or programmable through newly improved **TrakPro™ v5 Data Analysis Software**
- User-selectable alarm levels to alert workers to high aerosol concentrations
- Newly designed robust impactors enable reliable size fraction measurements at higher aerosol concentrations over longer run times
- Model AM520i designed and tested to pass Intrinsic safety requirements as established by IEC (International Electrotechnical Commission)— see TSI® App Note EXPMN-017 for a basic understanding of intrinsic safety



Specifications

SidePak™ Personal Aerosol Monitor

Models AM520 and AM520i

Sensitivity

Sensor Type 90° light scattering, 650 nm laser diode
Calibration Calibrated against a gravimetric reference using the respirable fraction of standard ISO 12103-1, A1 Test Dust

Aerosol
Concentration Range 0.001 to 100 mg/m³
Particle Size Range 0.1 to 10 µm
Minimum Resolution 0.001 mg/m³
Zero Stability ±0.001 mg/m³ over 24 hours using 10 second time constant
Temperature Coefficient Approximately +0.0005 mg/m³ per °C (for variations from temperature at which instrument was last zeroed)

Flow Rate

Range User-adjustable, 0 to 1.8 liters/min (L/min) Note: Upper range is dependent on impactor or cyclone attached to the SidePak™ AM520/520i Monitor

Temperature Range

Operating Range 32° F to 120° F (0° C to 50° C)
Storage Range -4° F to 140° F (-20° C to 60° C)
Operational Humidity 0 to 95% RH, non-condensing
Battery Charging 32°F to 113°F (0°C to 40°C)

Time Constant (OLED Display)

Range User-adjustable, from 1 to 60 seconds

Built-in Inlets

Standard inlet Not size-specific
PM1.0 impactor 50% cut-off at 1.0 µm
PM2.5 impactor 50% cut-off at 2.5 µm
PM5.0 impactor 50% cut-off at 5.0 µm
PM10 impactor 50% cut-off at 10.0 µm

Attachable Cyclones

4 µm Dorr-Oliver 50% cut-off at 4.0 µm
0.8 µm DPM 50% cut-off at 0.8 µm

Alarms

Alarm Types General, STEL
Default Settings 0.5 mg/m³, 1 mg/m³, 3 mg/m³, 5 mg/m³, 15 mg/m³, Off
Programmable 0 - 100 mg/m³ via TrakPro™ v5 Software
Alarm Indicator 95 dBA (at one foot) audible horn, blinking red LED, flashing red OLED display
Ringback Delay 30 sec, 1 min, 3 min, 5 min, 10 min, Off

Data Logging

Data Points Approx. 80,000 (55 days logging once per minute)
Logging Interval User-adjustable, from 1 second to 60 minutes

Communications Interface

Type USB 2.0
Connector, Instrument USB Micro-B (socket)

User-Select Calibration Factors

Factory Setting 1.0 (non-adjustable)
Ambient Setting 0.38 (non-adjustable)
User-Defined Settings 10, with user-defined labels via TrakPro™ v5 Software
Range 0.1 to 10.0, user-adjustable

Physical

External Dimensions 5.1 x 3.7 x 3.1 inch
129.5 mm x 94 mm x 78.4 mm with 803322 battery
Weight 22 oz (0.62 kg) with 803322 battery
Display 160 x 128 resolution color OLED display
Tripod Mounting Nut ¼"-20 female thread

Battery Pack (Model AM520 p/n 803300, Model AM520i p/n 803322)

Rating 5100 mAh Li-Ion Pack
Run Time Greater than 20 hours at 1.7Lpm with a PM2.5 impactor
Charge Time 4.0 hours (typical with a fully depleted battery)

Power Supply (p/n 803302)

Input Voltage Range 100 to 240 VAC, 50 to 60 Hz
Output Voltage 12 VDC @ 3.0A

Maintenance

Factory Clean/Calibrate Recommended annually
User Zero Calibration Before each use
User Flow Calibration As needed with use of Primary Flow Calibrator 4146

Minimum Computer Requirements for TrakPro Software

Communications Port Universal Serial Bus (USB) v2.0 or higher
Operating System Microsoft Windows® 7, 8, or 10 (32-bit or 64-bit) operating systems

Approvals



Model AM520



Model AM520i

Immunity EN61326-1:2013
Emissions EN61326-1:2013 Class B
Safety IEC 61010-1:2010
IEC 60825-1:2014

Intrinsically Safe SidePak™ AM520i Personal Aerosol Monitor

See specifications sheet for more details. Rated for use in atmospheres known to contain flammable gases and vapors, flammable fibers and flammable dust.

Explanation of intrinsic safety rating — Global Zone Rating: Ex ia IIC T4 Ga (see TSI App Note EXPMN-016 for further explanation of Model AM520i intrinsic safety rating and see TSI App Note EXPMN-017 for a basic understanding of intrinsic safety)

Certifications — IECEx, ATEX, CSA, IECEx SIM-19.0009X



Knowledge Beyond Measure.

TSI Incorporated - Visit our website www.tsi.com for more information.

USA Tel: +1 800 874 2811
UK Tel: +44 149 4 459200
France Tel: +33 1 41 19 21 99
Germany Tel: +49 241 523030
India Tel: +91 80 67877200
China Tel: +86 10 8219 7688
Singapore Tel: +65 6595 6388



Distributed by:

Kenelec Scientific Pty Ltd
1300 73 22 33
sales@kenelec.com.au
www.kenelec.com.au

Specifications are subject to change without notice.

TSI and the TSI logo are registered trademarks of TSI Incorporated in the United States and may be protected under other country's trademark registrations.

Microsoft Windows is a registered trademark of Microsoft Corporation in the United States and/or other countries.