

GENERAL PURPOSE WATER-BASED CONDENSATION PARTICLE COUNTER MODEL 3787

OPERATION AND SERVICE MANUAL



START SEEING THE BENEFITS OF REGISTERING TODAY!

Thank you for your TSI instrument purchase. Occasionally, TSI releases information on software updates, product enhancements and new products. By registering your instrument, TSI will be able to send this important information to you.

<http://register.tsi.com>

As part of the registration process, you will be asked for your comments on TSI products and services. TSI's customer feedback program gives customers like you a way to tell us how we are doing.



UNDERSTANDING, ACCELERATED

TSI Incorporated - Visit our website **www.tsi.com** for more information.

USA	Tel: +1 800 874 2811	India	Tel: +91 80 67877200
UK	Tel: +44 149 4 459200	China	Tel: +86 10 8251 6588
France	Tel: +33 491 11 87 64	Singapore	Tel: +65 6595 6388
Germany	Tel: +49 241 523030		

©2012 TSI Incorporated

Printed in U.S.A.



GENERAL PURPOSE
WATER-BASED CONDENSATION
PARTICLE COUNTER (GP-WCPC)
MODEL 3787

OPERATION AND SERVICE MANUAL

- 1 Product Overview
 - 2 Unpacking and Setting Up the Model 3787 GP-WCPC
 - 3 Moving and Shipping the Model 3787 GP-WCPC
 - 4 Instrument Description
 - 5 Instrument Operation
 - 6 Technical Description
 - 7 Particle Counting
 - 8 Computer Interface, Commands, and Data Collection
 - 9 Maintenance, Service, and Troubleshooting
- Appendixes

Manual History

The following is a history of the Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC) Operation and Service Manual (Part Number 6003712).

Revision	Date
Preliminary	October 2010
A	April 2011
B	April 2012
C	January 2013

Warranty

Part Number 6003712 / Revision C / January 2013
Copyright ©TSI Incorporated / All rights reserved.
Address TSI Incorporated / 500 Cardigan Road / Shoreview, MN 55126 / USA
Fax No. 651-490-3824
E-mail Address particle@tsi.com

Limitation of Warranty and Liability
(effective June 2011)

Seller warrants the goods sold hereunder, under normal use and service as described in the operator's manual, shall be free from defects in workmanship and material for **12 months**, or if less, the length of time specified in the operator's manual, from the date of shipment to the customer. **If tap water or a working fluid other than distilled (<6 ppm) or HPLC water is used in this instrument, the warranty will no longer be valid.** This warranty period is inclusive of any statutory warranty. This limited warranty is subject to the following exclusions and exceptions:

- a. Hot-wire or hot-film sensors used with research anemometers, and certain other components when indicated in specifications, are warranted for 90 days from the date of shipment;
- b. Pumps are warranted for hours of operation as set forth in product or operator's manuals;
- c. Parts repaired or replaced as a result of repair services are warranted to be free from defects in workmanship and material, under normal use, for 90 days from the date of shipment;
- d. Seller does not provide any warranty on finished goods manufactured by others or on any fuses, batteries or other consumable materials. Only the original manufacturer's warranty applies;
- e. Unless specifically authorized in a separate writing by Seller, Seller makes no warranty with respect to, and shall have no liability in connection with, goods which are incorporated into other products or equipment, or which are modified by any person other than Seller.

The foregoing is **IN LIEU OF** all other warranties and is subject to the **LIMITATIONS** stated herein. **NO OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR PARTICULAR PURPOSE OR MERCHANTABILITY IS MADE. WITH RESPECT TO SELLER'S BREACH OF THE IMPLIED WARRANTY AGAINST INFRINGEMENT, SAID WARRANTY IS LIMITED TO CLAIMS OF DIRECT INFRINGEMENT AND EXCLUDES CLAIMS OF CONTRIBUTORY OR INDUCED INFRINGEMENTS. BUYER'S EXCLUSIVE REMEDY SHALL BE THE RETURN OF THE PURCHASE PRICE DISCOUNTED FOR REASONABLE WEAR AND TEAR OR AT SELLER'S OPTION REPLACEMENT OF THE GOODS WITH NON-INFRINGEMENTS.**

TO THE EXTENT PERMITTED BY LAW, THE EXCLUSIVE REMEDY OF THE USER OR BUYER, AND THE LIMIT OF SELLER'S LIABILITY FOR ANY AND ALL LOSSES, INJURIES, OR DAMAGES CONCERNING THE GOODS (INCLUDING CLAIMS BASED ON CONTRACT, NEGLIGENCE, TORT, STRICT LIABILITY OR OTHERWISE) SHALL BE THE RETURN OF GOODS TO SELLER AND THE REFUND OF THE PURCHASE PRICE, OR, AT THE OPTION OF SELLER, THE REPAIR OR REPLACEMENT OF THE GOODS. IN THE CASE OF SOFTWARE, SELLER WILL REPAIR OR REPLACE DEFECTIVE SOFTWARE OR IF UNABLE TO DO SO, WILL REFUND THE PURCHASE PRICE OF THE SOFTWARE. IN NO EVENT SHALL SELLER BE LIABLE FOR LOST PROFITS OR ANY SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES. SELLER SHALL NOT BE RESPONSIBLE FOR INSTALLATION, DISMANTLING OR REINSTALLATION COSTS OR CHARGES. No Action, regardless of form, may be brought against Seller more than 12 months after a cause of action has accrued. The goods returned under warranty to Seller's factory shall be at Buyer's risk of loss, and will be returned, if at all, at Seller's risk of loss.

Buyer and all users are deemed to have accepted this LIMITATION OF WARRANTY AND LIABILITY, which contains the complete and exclusive limited warranty of Seller. This LIMITATION OF WARRANTY AND LIABILITY may not be amended, modified or its terms waived, except by writing signed by an Officer of Seller.

Service Policy

Knowing that inoperative or defective instruments are as detrimental to TSI as they are to our customers, our service policy is designed to give prompt attention to any problems. If any malfunction is discovered, please contact your nearest sales office or representative, or call the TSI Customer Service department at 1-800-874-2811 (USA) or (651) 490-2811.

Trademarks

Scanning Mobility Particle Sizer, SMPS, Environmental Particle Counter, and EPC are trademarks of TSI Incorporated. Aerosol Instrument Manager is a registered trademark of TSI Incorporated.

IBM is a registered trademark of International Business Machines Corporation in the United States, other countries, or both.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

Safety

This chapter provides instructions to promote safe handling and correct operation of the Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC).

There are limited user-serviceable parts inside the GP-WCPC. All repair and maintenance should be done by qualified, trained technicians. All maintenance and repair information in this manual is included for use by a qualified, trained technician.



WARNING

It is unsafe to operate this instrument in a manner other than that described in this manual. Failure to follow all of the procedures described in this manual can result in serious injury to you or cause irrevocable damage to the instrument.

Laser Safety

The Model 3787 GP-WCPC is a Class I laser-based instrument. During normal operation, you will not be exposed to laser radiation. To avoid exposing yourself at any time to hazardous radiation in the form of intense, focused visible light (exposure to this light can cause blindness), take these precautions:

- Do **not** remove any parts from the GP-WCPC unless specifically told to do so in this manual.
- Do **not** remove the GP-WCPC housing or cover while power is supplied to the instrument.



WARNING

The use of controls, adjustments, or procedures other than those specified in this manual may result in exposure to hazardous optical radiation.

Description of Safety Labels

This information explains the advisory and identification labels used on the instrument and in this manual to reinforce the safety features built into the instrument.

Caution



C a u t i o n

Caution means *be careful*. If you do not follow the procedures described in this manual you may damage the instrument or you may have to begin again. Caution also indicates important information about the operation and maintenance of this instrument.

Warning



W A R N I N G

Warning means that unsafe use of the instrument could result in serious injury to you or cause irrevocable damage to the instrument. Follow the procedures prescribed in this manual to use the instrument safely.






Caution or Warning Symbols

The following symbols may accompany cautions and warnings to indicate the nature and consequences of hazards:

	Warns you that un-insulated voltage within the instrument may have sufficient magnitude to cause electric shock. It is dangerous to make any contact with any part inside the instrument.
	Warns you that the instrument contains a laser and that important information about its safe operation and maintenance is included. Read the manual carefully to avoid any exposure to hazardous laser radiation.
	Warns you that the instrument is susceptible to electro-static dissipation (ESD). ESD protection procedures should be followed to avoid damage.
	Indicates the connector is connected to earth ground and cabinet ground.

Labels

Advisory labels and identification labels are attached to the outside of the GP-WCPC housing and to the optics on the inside of the instrument. Labels for the Model 3787 GP-WCPC are described below:

<p>Serial Number Label—displayed on the back panel.</p>	
<p>Laser safety warning label—displayed inside the GP-WCPC near the laser diode assembly.</p>	
<p>High Voltage warning sticker—displayed inside the GP-WCPC.</p>	
<p>Class 1 Laser certification and identification label—displayed on the back panel. When operated according to the manufacturer's instruction, this device is a Class I laser product as defined by U.S. Department of Health and Human Services standards under the Radiation Control for Health and Safety Act of 1968.</p>	
<p>TSI Service Label—displayed on the back panel.</p>	

(This page intentionally left blank)

Contents

Manual History	iv
Warranty	v
Safety	vii
Laser Safety	vii
Description of Safety Labels	viii
Caution.....	viii
Warning.....	viii
Caution or Warning Symbols	viii
Labels.....	ix
About This Manual	xvii
Purpose.....	xvii
Organization.....	xvii
Related Product Literature	xviii
Getting Help	xviii
Submitting Comments.....	xix
CHAPTER 1 Product Overview	1-1
Product Description.....	1-1
Acknowledgement.....	1-2
How it Works	1-3
CHAPTER 2 Unpacking and Setting Up the Model 3787 GP-WCPC ... 2-1	
Packing List.....	2-1
Unpacking	2-2
Installation	2-3
Equipment.....	2-3
Remove Protective Caps	2-3
Connecting the Water Supply	2-3
Connecting the Aerosol Sample	2-5
Connecting the USB Cable.....	2-6
Connecting the Power and Warming Up the GP-WCPC.....	2-6
CHAPTER 3 Moving and Shipping the Model 3787 GP-WCPC	3-1
Moving the Model 3787 GP-WCPC Short Distances	3-1
Preparing the Model 3787 GP-WCPC for Shipping and Storage....	3-1
CHAPTER 4 Instrument Description	4-1
Front Panel.....	4-1
Display	4-1
Status Indicators	4-2
Indicator Light	4-2
Back Panel	4-3
CHAPTER 5 Instrument Operation	5-1
Operating Precautions	5-1
Recommended Operation Procedures	5-1
General Operation Procedures.....	5-1
Standard Operation Procedures	5-2

Sampling Outdoor Aerosols	5-2
Warm-up	5-3
Display/User Settings	5-3
HOME Screen	5-3
STATUS Screens	5-3
SETUP Screens	5-5
TOTAL Screen.....	5-10
CHAPTER 6 Technical Description	6-1
Theory.....	6-1
History.....	6-2
Design of the Model 3787	6-3
Sensor	6-3
Flow System	6-4
Critical Flow	6-5
Temperature Control	6-5
Inlet Pressure Measurement	6-5
Water Removal System.....	6-6
Internal Clock.....	6-6
Counting Efficiency and Response Time of the Model 3787.....	6-6
CHAPTER 7 Particle Counting	7-1
Total Count Accuracy	7-2
Live-Time Counting.....	7-2
Concentration Measurement	7-3
Totalizer Mode	7-5
CHAPTER 8 Computer Interface, Commands, and Data Collection ..	8-1
Analog Inputs.....	8-1
Analog Output.....	8-1
Pulse Output	8-2
Computer Interface	8-2
Ethernet	8-3
Flash Drives.....	8-4
USB	8-6
RS-232 Serial Communications	8-7
Terminal Communications.....	8-8
Aerosol Instrument Manager® Software	8-9
Commands.....	8-9
CHAPTER 9 Maintenance, Service, and Troubleshooting	9-1
Removing the Cover	9-2
Replacement Parts Kits	9-2
Internal Instrument Components	9-3
Optics Module.....	9-5
Vacuum Pump	9-5
Water System	9-5
Fans.....	9-6
Circuit Boards	9-6
Changing the Filters.....	9-7
Removing and Installing the Wick	9-7
Flow Checks	9-10
Cleaning the Water Bottle.....	9-11
Inspecting and Cleaning the Fans	9-12
Clean/Replace the Orifices	9-12
Inspect Tubing	9-13

Status Messages	9-14
Troubleshooting	9-15
Technical Contacts	9-16
Returning the Model 3787 for Service	9-17
APPENDIX A Specifications	A-1
APPENDIX B Firmware Commands.....	B-1
READ Commands.....	B-2
RAI – Read Analog Input Voltage.....	B-2
RALL – Read Operating Condition	B-2
RCT – Read Current Time.....	B-3
RD – Read Displayed Concentration.....	B-3
RIE – Read Instrument Errors	B-4
RIF – Read Aerosol Flow Rate	B-4
RIS – Read Instrument Status	B-5
RL – Read Laser Current.....	B-5
RLL – Read Liquid Level	B-6
RPA – Read Absolute Pressure Transducer.....	B-6
RPN – Read Nozzle Pressure Transducer.....	B-6
RPV – Read Nozzle Pressure Transducer	B-6
RRD – Read Data Record	B-7
RRS – Read Status Record.....	B-8
RSF – Read Sample Flow Rate	B-8
RTA – Read Cabinet Temperature.....	B-8
RTC – Read Condenser Temperature	B-9
RTG – Read Growth Tube Temperature	B-9
RTO – Read Optics Temperature.....	B-9
RV – Read Firmware Version Number	B-9
SET Commands.....	B-10
SM – Set Mode	B-10
SFC – Set Flow Rate Calibration Constant	B-11
SP – Set Pump Vacuum.....	B-11
SR – Set Real-time Clock.....	B-12
SSTART – Starts a New Sample.....	B-13
ST – Set Transport Flow.....	B-14
SMPS™ Spectrometer Scanning Commands	B-14
ZB – Begins SMPS™ Spectrometer Scan	B-14
ZE – Ends SMPS™ Spectrometer Scan	B-14
ZT – Sets SMPS™ Spectrometer Scan Time	B-15
ZU – Sets SMPS™ Spectrometer Scan Direction Up	B-15
ZV – Sets SMPS™ Spectrometer Scan Voltages	B-15
DATA Reporting Records	B-16
D Record.....	B-16
S Record (Status)	B-16
U Record.....	B-17
APPENDIX C References	C-1
Index	
Reader’s Comments Sheet	

Figures

1-1	Model 3787 General Purpose Water-based Condensation Particle Counter.....	1-2
1-2	General Purpose Water-based Condensation Particle Counter Diagram	1-4
2-1	Attaching the Water Bottle Bracket	2-4
2-2	Attaching the Water Bottle Tubing Connections	2-5
2-3	Connecting the Aerosol Supply	2-6
2-4	Warm-up Screen	2-7
4-1	General Purpose Water-based Condensation Particle Counter Front Panel.....	4-1
4-2	General Purpose Water-based Condensation Particle Counter Back Panel	4-3
5-1	Status Screens	5-4
6-1	Detection Efficiency Curve of Model 3787 General Purpose Water-based Condensation Particle Counter.....	6-7
6-2	Response Time of Model 3787	6-7
8-1	Screen Showing Valid Network Connection.....	8-4
9-1	General Purpose Water-based Condensation Particle Counter Internal Components (viewed from left side).....	9-3
9-2	General Purpose Water-based Condensation Particle Counter Internal Components (viewed from right side).....	9-4
9-3	General Purpose Water-based Condensation Particle Counter Internal Components (viewed from above and front)	9-5
9-4	Water-based Condensation Particle Counter Wick Assembly	9-6
9-5	Wick Cartridge, Growth Tube separated from Conditioner	9-6
9-6	Filter noting Direction of Flow	9-7
9-7	Inlet Jack Screw. Inlet Block Removal with the Hex Wrench	9-8
9-8	GP-WCPC Wick Cartridge from Inlet Assembly.....	9-8
9-9	Inserting New Wicks in Wick Cartridges.....	9-9
9-10	General Purpose Water-based Condensation Particle Counter Flow Schematic	9-10
9-11	Aerosol Inlet.....	9-11
9-12	Arrow Showing Direction of Flow on Orifice.....	9-12
9-13	Inspect Orifice.....	9-12

Tables

2-1	Model 3787 Nano Water-based Condensation Particle Counter Packing List	2-1
2-2	Model 3787 Nano Water-based Condensation Particle Counter Maintenance Kit	2-2
9-1	Model 3787 GP-WCPC Maintenance and Replacement Kits	9-2
9-2	Status Messages	9-14
9-3	Troubleshooting	9-15
A-1	Model 3787 Nano Water-based Condensation Particle Counter Specifications.....	A-1
B-1	Model 3787 Firmware Commands	B-1

(This page intentionally left blank)

About This Manual

Purpose

This is an operation and service manual for the Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC).

Organization

The following information is a guide to the organization of this manual.

- **Chapter 1: Product Overview**
Contains an introduction to the Model 3787 GP-WCPC, a list of features, and a brief description of how the instrument works.
- **Chapter 2: Unpacking and Setting Up the Model 3787 GP-WCPC**
Contains a packing list and the step-by-step procedures for installing the Model 3787 GP-WCPC.
- **Chapter 3: Moving and Shipping the Model 3787 GP-WCPC**
Describes how to prepare the GP-WCPC for moving and shipping.
- **Chapter 4: Instrument Description**
Describes features and controls that run the GP-WCPC, including the components on the front-panel, back-panel, and inside the instrument. It also covers the basic functions of the instrument.
- **Chapter 5: Instrument Operation**
Describes the operation of the Model 3787 GP-WCPC.
- **Chapter 6: Technical Description**
Describes the principle of operation, theory, and performance of the Model 3787 GP-WCPC.
- **Chapter 7: Particle Counting**
Contains information about the particle counting modes.
- **Chapter 8: Computer Interface, Commands, and Data Collection**
Describes the computer interface, commands and data collection.
- **Chapter 9: Maintenance, Service, and Troubleshooting**
Describes the recommended practices for routine maintenance and service, as well as important troubleshooting procedures.
- **Appendix A: Specifications**
Contains the specifications of the Model 3787 GP-WCPC.

- **Appendix B: Firmware Commands**
Lists all the serial commands for communications between the Model 3787 GP-WCPC and the computer.
- **Appendix C: References**
Contains a list of the references that have been used within the text of the manual as well as a general list of references pertaining to condensation nucleus counters.

Related Product Literature

- **Model 3007 Condensation Particle Counter Operation and Service Manual** (part number 1930035) TSI Incorporated
- **Model 3772/3771 Condensation Particle Counter Operation and Service Manual** (part number 1980529) TSI Incorporated
- **Model 3775 Condensation Particle Counter Operation and Service Manual** (part number 1980527) TSI Incorporated
- **Model 3781 Water-based Condensation Particle Counter Operation and Service Manual** (part number 1930111) TSI Incorporated
- **Model 3783 EPC™ Environmental Particle Counter™ Monitor Operation and Service Manual** (part number 6003653) TSI Incorporated
- **Model 3788 Nano Water-based Condensation Particle Counter Operation and Service Manual** (part number 6003713) TSI Incorporated
- **Aerosol Instrument Manager® Software for CPC and EAD Instruction Manual** (part number 1930062) TSI Incorporated

This manual contains operating instructions for Aerosol Instrument Manager® Software for CPC and EAD, a software program that monitors, calculates, and displays particle concentration data collected by a CPC or an EAD.

Getting Help

To obtain assistance with the Model 3787 General Purpose Water-based Condensation Particle Counter, contact TSI Customer Service:

TSI Incorporated
500 Cardigan Road
Shoreview, MN 55126 USA
Fax: (651) 490-3824
Telephone: 1-800-874-2811 (USA) or (651) 490-2811
E-mail Address: technical.service@tsi.com

Submitting Comments

TSI values your comments and suggestions on this manual; please use the comment sheet on the last page to send us your opinion on the manual's usability, to suggest specific improvements, or to report any technical errors.

If the comment sheet has already been used, please mail your comments on another sheet of paper to:

TSI Incorporated
Particle Instruments
500 Cardigan Road
Shoreview, MN 55126
Fax: (651) 490-3824
E-mail address: particle@tsi.com

(This page intentionally left blank)

CHAPTER 1

Product Overview

This chapter contains an introduction to the Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC) and provides a brief explanation of how the instrument operates.

Product Description

The Model 3787 GP-WCPC is designed primarily for researchers interested in detecting airborne particles in the ultrafine particle size range. It detects particles down to 5 nm, and has a selectable inlet flow rate (1.5 or 0.6 L/min).

Patented technology enables the Model 3787 GP-WCPC to use water as a condensing fluid to enlarge submicrometer particles so that they can be easily detected. The Model 3787 GP-WCPC provides rapid, high-precision measurement of the numbers of ultrafine (down to 5 nm) airborne particles. The instrument has a wide, dynamic, particle-concentration range for small-particle detection in the laboratory setting and can be used for a variety of applications including research, indoor air quality investigations, atmospheric and climate research, health effects studies. Particle concentration, total counts, or plots of concentration versus time can be displayed on the front panel. The Model 3787 GP-WCPC is compatible with SMPS™ systems and TSI's Aerosol Instrument Manager® software. TSI recommends annual maintenance and calibration for the Model 3787 GP-WCPC instrument.

Features of the Model 3787 GP-WCPC include:

- 6-inch QVGA color touch screen with a graphical interface displaying particle concentration, total counts, and a plot of concentration vs. time.
- 5-nm detection with a sharp D_{50} efficiency curve.
- Wide, dynamic particle-concentration range for small-particle detection.
- Single-particle counting to 2.5×10^5 particles/cm³.
- Continuous, live-time, electronic processing for maximum accuracy.
- Selectable inlet flow (1.5 or 0.6 L/min).
- Fast response time (<2 sec).
- Flexible data acquisition options including USB flash drive (or memory stick), Ethernet, USB port, and RS-232 port.
- Advanced instrument diagnostics including a novel pulse height analyzer to monitor super-saturation state, wick health, and instrument status.

- Newly designed air flow, wicking, and water handling systems. The use of a sheath air flow reduces diffusion losses.
- Works as part of an SMPS™ system.




Figure 1-1
Model 3787 General Purpose Water-based Condensation Particle Counter

Acknowledgement

The continuous, laminar-flow, water-based condensation principle on which this product is based is patented technology licensed from Aerosol Dynamics Inc. of Berkeley, CA (U.S. Patent 6712881). We give our sincere thanks to Susanne V. Hering PhD and Mark R. Stolzenburg PhD for their invention, their clever insights to this unique technology, their numerical models, and the gracious feedback they have provided during the development of this product.

How it Works

The Model 3787 GP-WCPC is a water-based condensation particle counter designed to measure the number concentration of sub-micrometer airborne particles. The GP-WCPC draws in an air sample and counts the number of particles in that sample to provide a particle concentration value that is displayed as the number of particles detected per cubic centimeter of sampled air.

The GP-WCPC uses a patented* technology to condense water vapor onto particles, growing them into droplets which are then detected by a conventional optical counting system. The stream of aerosol particles is uninterrupted and follows a laminar flow path from the sample inlet to the optical detector.

The GP-WCPC particle counting process is as follows:

1. The aerosol enters the sample inlet at a flow rate of 0.6 L/min or 1.5 L/min (depending upon the setting for the transport flow).

Note: *The transport flow allows fast transportation of the aerosol to the inlet to reduce particle loss.*

2. In the Conditioner, the aerosol sample stream is saturated with water vapor and then equilibrated for temperature and humidity.
3. The sample passes to a growth tube where the wetted walls are heated to raise the vapor pressure. The high diffusivity of the water vapor allows the vapor to reach the center of the sample stream at a faster rate than the thermal diffusivity of the vapor can equilibrate to the higher temperatures near the walls—creating a supersaturated condition along the radius of the flow stream. These unstable conditions facilitate water condensation on the sample particles.
4. Particles that are larger than the detection limit of the GP-WCPC's critical particle size act as condensation nuclei as they pass up the growth tube.
5. The enlarged droplets are detected by the optical detector where a laser illuminates the viewing volume. A light pulse from each particle is converted to an electrical signal that is processed by the GP-WCPC electronics.

Figure 1-2 illustrates the flow system of the GP-WCPC.

* US Patent No. 6,712,881 Aerosol Dynamic Inc., Drs. Susanne V. Hering and Mark Stolzenburg




Figure 1-2
General Purpose Water-based Condensation Particle Counter Diagram

CHAPTER 2

Unpacking and Setting Up the Model 3787 GP-WCPC

Use the information in this chapter to unpack and set up the Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC).

Packing List

Table 2-1 shows the components shipped with the Model 3787 General Purpose Water-based Condensation Particle Counter.

Table 2-1
Model 3787 General Purpose Water-based Condensation Particle Counter
Packing List

Qty.	Part Number/ Model Number	Description
1	3787	General Purpose Water-based Condensation Particle Counter (GP-WCPC)
1	6003712	Operation and Service Manual
1	6004401	Model 3787 Quick Start Guide
1	N/A	Power cable
1	1183007	Recycle fill bottle
1	N/A	Water supply bottle mounting bracket with 2x screws (6-32 x 3/8 inch)
1	N/A	Calibration Certificate
1	1303740	Computer cable, USB A to B
1	962002	RS-232 Serial cable
1	390065	Aerosol Instrument Manager® Software
1	1187001	Maintenance Kit (for details see Table 2-2 below)

Note: Some items above and those for future maintenance are available for purchase as kits from TSI. A complete list of replacement part kits is included in the [Maintenance](#) section in Chapter 9.

Table 2-2

Model 3787 General Purpose Water-based Condensation Particle Counter Maintenance Kit (Part Number 1187001)

Qty.	Part Number	Description
1	1180003	3787 Replacement wicks (pack of 12)
1	1180008	3787/88 Replacement Wick Cartridge
1	1180004	3787 Replacement Critical Flow Control Orifice .011 inch
1	1180005	3787 Replacement Critical Transport Flow Control Orifice .0135 inch
1	1183004	3787 Replacement Filter: Replacement for Critical Flow Control Orifice, Critical Transport Orifice, and Pump Exhaust.
1	N/A	Three-foot length of 1/8 inch tubing

Unpacking

Carefully unpack the Model 3787 GP-WCPC from the shipping container. Use the Packing List in Table 2-1 to verify that there are no missing components.

Save the original shipping container to be used for future shipping.

If anything is missing, or appears to be damaged, contact your TSI representative or TSI Customer Service using one of the following methods:

Telephone: 1-800-874-2811 (within the US)
001-651-490-2811 (outside the US)

E-mail: technicalservice@tsi.com

See [Chapter 9](#) for instructions on how to return the instrument to TSI.



Caution

The Model 3787 GP-WCPC operates using distilled (<6 ppm) or HPLC water as a working fluid. Do **not** tip the instrument more than 10 degrees during normal operation or you may flood the system. Perform the procedures described in [Chapter 3](#) before moving or shipping the instrument.

Do not:

- Ship an “undried” instrument.
- Transport an “undried” instrument over long distances.
- Subject an “undried” instrument to freezing temperatures.

Any of the above actions can result in the flooding of the optical system, performance degradation, and possible damage to the instrument. Such neglect is not covered under the manufacturer’s warranty.

Installation

This section contains instructions for installing the Model 3787 GP-WCPC. Follow the instructions in the order given.

The installation procedures, described on the following pages, include the following:

- [Removing protective caps.](#)
- [Connecting the water supply.](#)
- [Connecting the aerosol sample.](#)
- [Connecting the USB cable.](#)
- [Connecting the power and warming up the Model 3787 GP-WCPC.](#)

Equipment

You will need the following to install the GP-WCPC:

- Phillips screwdriver.
- Water supply.

Note: Use either distilled or ultrapure water. Do **not** use tap water.

Remove Protective Caps

After unpacking the GP-WCPC, remove any protective caps from the **AEROSOL INLET** and remove any covers from the BNC connectors.

Connecting the Water Supply

The Model 3787 GP-WCPC uses a gravity-fed water fill system, and a fill bottle designed to recycle water.

Note: To prevent the water from draining back into the instrument during operation, the bottle must always be placed at a higher level than the instrument.

To connect the water supply, follow these instructions:

1. Attach the water supply bottle bracket to the back of the GP-WCPC using the provided bottle bracket and mounting screws.




Figure 2-1
Attaching the Water Bottle Bracket

2. Fill the water supply bottle with either distilled (<6 ppm) or HPLC water.
3. Remove any air from the water supply line by pressing the connector (valve) at the end of the supply tube onto a hard surface and allowing the air to bleed from the tubing.
4. Place the bottle in the bracket.
5. Push the connector on the tubing at the **bottom** of the water supply bottle into the **WATER FILL** fitting on the back of the instrument.
6. Push the connector on the tubing at the **top** of the water supply bottle into the **WATER EXHAUST** fitting on the back of the instrument.



Figure 2-2
Attaching the Water Bottle Tubing Connections

Connecting the Aerosol Sample

The Sample inlet for the Model 3787 GP-WCPC is located on the front of the instrument. Options for connection to the instrument include

- SMPS™ spectrometer sampling using an electrostatic classifier.
- Using a sampling system connected directly to the aerosol inlet.
- Environmental monitoring using tubing connected directly to the aerosol inlet.

Note: *The Model 3783 EPC™ Environmental Particle Counter™ monitor is the preferred instrument for this application.*



IMPORTANT

The gauge pressure of the sampled aerosol must be within $\pm 10/-50$ mbar ($\pm 4/-20$ in H₂O) pressure relative to the ambient pressure.

To set up the aerosol supply, connect the aerosol sample line to the aerosol inlet.



Figure 2-3
Connecting the Aerosol Supply

Connecting the USB Cable

Connect the provided USB cable to the USB connector on the back panel of the Model 3787 GP-WCPC.

Connecting the Power and Warming Up the GP-WCPC

After you connect the power, the first-time warm-up process takes approximately 20 to 60 minutes (depending upon the amount of air in the water supply lines). Subsequent warm-up times are typically less than 20 minutes.

Follow these instructions to connect the power and warm up the Model 3787 GP-WCPC:

1. Plug the power cord (provided) with the Model 3787 GP-WCPC into the power connector (100 to 240 VAC 50/60 Hz 200 VA) on the back panel.
2. Plug the cord into an earth-grounded AC power source (100 to 240 VAC, 50/60 Hz, 2.0 A).



WARNING

Connection to an improperly grounded electrical source may cause a severe shock hazard—ensure that the ground is secure.

3. Turn on the instrument. The Home screen appears on the display and reads **WARMUP**. During the warm-up process, status messages are displayed at the top left of the home screen. The instrument status can be viewed by pressing the **STATUS** button on the home screen.




Figure 2-4
Warm-up Screen

4. When the warm-up is complete, if all conditions for operation are in place, the display reads **Ready**. If you do not see the **Ready** message, check the settings with the **SETUP** button and make sure the pump is turned on. On the initial startup of a dry instrument, it may take an additional 10 or 20 minutes after the internal water reservoirs are filled before the internal wicks are wetted and functional.

(This page intentionally left blank)

CHAPTER 3

Moving and Shipping the Model 3787 GP-WCPC

Use the information in this chapter to prepare the Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC) for moving or shipping.



Caution

The Model 3787 GP-WCPC operates using distilled (<6 ppm) or HPLC water as a working fluid. Do **not** tip the instrument more than 10 degrees during normal operation or you may flood the system.

Do **not**:

- Ship an “undried” instrument.
- Transport an “undried” instrument over long distances.
- Subject an “undried” instrument to freezing temperatures.

Any of the above actions can result in the flooding of the optical system, performance degradation, and possible damage to the instrument. Such neglect is not covered under the manufacturer’s warranty.

Moving the Model 3787 GP-WCPC Short Distances

You can successfully transport the Model 3787 GP-WCPC short distances from one lab to another, or even a short drive in a vehicle, without drying it first. However, do **not** tip the instrument more than 45° degrees and do **not** subject it to prolonged freezing temperatures.

Preparing the Model 3787 GP-WCPC for Shipping and Storage

To prepare the GP-WCPC for shipping, follow these instructions:

1. Turn on the GP-WCPC and allow it to warm up. The display screen reads **Ready** when the warm-up is complete and all the settings are correct.
2. Disconnect the water bottle, empty it, and then reconnect it.
3. Disconnect any connections to the aerosol inlet.

4. Allow the instrument to sample room air. The displayed particle concentration displayed will drop to <10 particles/cm³ as the growth tube wick dries out. Ten minutes after the concentration drops to this level, the instrument is sufficiently dry for shipment.

Note: *This drying out period typically takes less than 60 minutes, but extended drying periods will not harm the instrument.*

5. Disconnect the water bottle.
6. Turn off the power.
7. Carefully place the instrument in the original packing materials.

The Model 3787 GP-WCPC is now ready for shipping or storage.

CHAPTER 4

Instrument Description

Use the information in this chapter to become familiar with the location and function of controls, indicators, and connectors on the Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC).

Front Panel

The main components of the front panel are shown in the figure below.



Figure 4-1
General Purpose Water-based Condensation Particle Counter Front Panel

Display

The QVGA color LCD display provides continuous real-time display of sample data as well as user menus and status information. Press the display “buttons” to move from one screen to another or to record settings.

Status Indicators

Status indicators are displayed at the top of the home screen. The indicators are as follows:

Status Indicator	Description
Low Water	Water level is low
Warmup	Instrument is warming up
Environment Temp Fault	The environmental temperature is outside the operating range of the instrument
Laser Fault	Laser fault
Inlet Pressure Fault	Inlet pressure is too high/low
Vacuum Fault	Insufficient vacuum
Nozzle Fault	Plugged Nozzle or filter
Absolute Pressure Fault	Barometric (Inlet) pressure is out of range
Optics Temp Fault	Optics temperature is out of range
Growth Tube Temp Fault	Growth Tube temperature is out of range
Conditioner Temp Fault	Conditioner temperature is out of range
Separator Temp Fault	Separator temperature is out of range
Pulse Height Fault	Low pulse height
Ready	Warm-up process has finished, the pump is on, and all operating parameters are in range. The instrument is ready for use

Note: *The fault indicators on the front-panel display are a warning that the instrument is not ready for operation. However, only one indicator can display at a time. Check the Status screen for more specific details about the operating condition of the instrument.*

Indicator Light

The blue indicator light flashes once for each particle detected. At particle concentrations >100 particles/cm³, the flashing becomes a nearly continuous glow.

Back Panel

The main components of the back panel are shown in Figure 4-2. Components include power and data connections, analog input/output connections, and water and sample inlets/outlets.




Figure 4-2
General Purpose Water-based Condensation Particle Counter Back Panel

(This page intentionally left blank)

CHAPTER 5

Instrument Operation

This chapter describes the basic operation of the Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC) and describes how to use the controls, indicators, and connectors found on the front and back panels.

Operating Precautions

Read the following before applying power to the GP-WCPC:

- Review the operating specifications for the GP-WCPC described in [Appendix A](#).
- Do **not** operate the GP-WCPC at temperatures outside the range of 10 to 35°C. If the GP-WCPC is operated outside this range, the displayed concentration may be inaccurate.
- Use the GP-WCPC to sample particles in air or nitrogen only.



WARNING

The Model 3787 GP-WCPC should not be used with hazardous gases such as hydrogen or oxygen. Using the particle counter with hazardous gases may cause injury to personnel and damage to equipment.

Recommended Operation Procedures

General Operation Procedures

Follow these procedures when operating the GP-WCPC:

- Use short sampling lines—particles <10 nm are easily lost in sampling lines.
- Site the GP-WCPC as close as possible to the aerosol source to keep particle loss to a minimum.
- Use the 1.5 L/min inlet flow setting when possible to minimize the transit time and to minimize particle loss in sampling lines.
- Inlet pressure must be within the range of the instrument. Inlet pressures above 1 kPa (4 inches/H₂O) will not allow the gravity-fed water system to supply water. The internal vacuum pump will shut down if detected negative pressures drop below the specified operating range.

- Do **not** use tap water. Fill the water bottle with 1 liter of distilled (<6 ppm) or HPLC water.
- Check the inlet pressure using one of the following methods:
 - Check the inlet pressure valve on the status screen. Disconnect the aerosol inlet flow and then check the pressure again. The pressure should not drop by more than 250 mbars.
 - Turn the vacuum off and check the pressure.
- Check the **STATUS** screen to make sure the parameters are still accurate.
- Check the time and date on the Flash Drive every two weeks.

Standard Operation Procedures

Perform these standard procedures every 4 weeks (~700 hours):

- Replace the wick.
- Check the flow using a volumetric flowmeter.
- Fill the water bottle with 1 liter of distilled (<6 ppm) or HPLC water. **Do not use tap water.**
- Check the status screen to make sure the parameters are still accurate.
- Check the time and date.

Perform these standard procedures annually:

- Replace the filters.
- Perform a Zero check by placing a HEPA filter on the GP-WCPC monitor inlet and ensuring that particle concentration is >0.01 particles/cm³.

Note: Detailed information about these procedures can be found in the Maintenance section of [Chapter 9](#).

Sampling Outdoor Aerosols

Follow these procedures when sampling outdoors:

- The GP-WCPC should be operated in an environment that meets the temperature and humidity specifications.
- Use short sampling lines and an additional transport flow to keep transport times low and minimize particle loss.
- If the GP-WCPC is placed in an environment with temperatures lower than the ambient temperature, consider heating the sample line to reduce condensation, or consider preventing condensation in sampling lines by adding dryers or a sample conditioner.
- Use a particle size pre-cut (<3 µm), such as a cyclone or impactor, when directly sampling an outdoor sample. This protects the instrument from large particles or insects.

Warm-up

When you have successfully made all the connections described in the Installation section of [Chapter 2](#), and turned on the power, the Home screen appears on the display and reads **Warmup**. When the warm-up process is complete, and optics and growth tube temperatures are within two degrees of their standard operating temperatures, the display reads **Ready**. Use the menus to do the following:

- Turn flow on and off.
- Set the date and time.
- Set sampling parameters.
- Check flow.
- Collect Data.
- Set the network and data collection options.

Display/User Settings

Read this section for details of the screens, how to make selections, and how to change options.

HOME Screen

The Home screen displays a real-time sample graph of the concentration in particles/cm³, the **STATUS** of the instrument, and the **SETUP** and **TOTAL** options. To return to the Home screen from any other screen press **HOME**.

The following screens are accessible from the home screen and are described on the following pages:

- STATUS
- SETUP
- TOTAL

STATUS Screens

The two **STATUS** screens display a variety of real-time readings to give you an instant view of the operational status of the instrument. The following status colors are significant:

- Red indicates a parameter that is “out of range.”
- Yellow indicates something “in process.”
- White indicates “normal” conditions.

Press **MORE** on the first Status screen to see the **ADDITIONAL STATUS** settings. The photos below show the **STATUS** and **ADDITIONAL STATUS** screens.





Figure 5-1
Status Screens

The Status screens display the following information:

Status	Description
Concentration	Particle concentration represented in particles/cm ³ .
Pulse Height	Particle pulse signal height in mV. The pulse is a measure of the average pulse height, varies with particle concentration, and is useful for indicating wick problems.
Optics Temp	Temperature of the Optics in degrees Celsius. A normal Optics temperature is 60°C.
Growth Tube Temp	Temperature of the Growth Tube in degrees Celsius. A normal Growth Tube temperature is 60°C.
Conditioner Temp	Temperature of the Conditioner in degrees Celsius. A normal Conditioner temperature is 20°C.
Vacuum	The vacuum pressure in mbars (must be less than half of the inlet pressure).
Inlet Pressure	The atmospheric pressure in mbars. This parameter is preset and can be used to indicate a blockage.

Status	Description
Nozzle Pressure	The pressure difference upstream and downstream of the optics assembly. Nominally 100%.
GT Reservoir	Indicates whether the growth tube reservoir is Filled/Not Filled.
Cond Reservoir	Indicates the status of the conditioner reservoir— Filled/Not Filled.
Separator Temp	Temperature of the Separator in degrees Celsius. A normal Separator temperature is 7°C.
Cabinet Temp	Temperature at the inlet of the Model 3787.
Laser Current	The operating current of the laser in mA.
Photodetector	Indicates photodetector voltage in mV.
Analog Input	Displays the voltage of the analog input.
Flow Constant	Flow calibration constant represented in cm ³ /min. This constant (set in the firmware) corrects for actual flow through the flow control orifice. The nominal flow value is 600 cm ³ /min.

SETUP Screens

HOME | SETUP

Pressing the **SETUP** button on the home screen takes you to the **SETUP** screen where the following operating parameters can be set:

Parameter	Description
SAMPLE TIME	Select a sample time for updating the display graph. Choices are 1 sec, 2 sec, 3 sec, 4 sec, 5 sec, 6 sec, 10 sec, 12 sec, 15 sec, 20 sec, 30 sec, 60 sec.
PUMP	Select the vacuum pump settings, turning the pump on or off.
INLET FLOW	Set the inlet flow. Choices are 1.5 L/min (total flow), and 0.6 L/min (sample flow).
SET TIME	Set the time for the internal, real-time clock used for data logging purposes.

Parameter	Description
MORE	Takes you to the NETWORK SETUP screen.
NETWORK SET UP	Set up network connections including NETWORK, ADDRESS, MASK, and GATEWAY.
MORE	Takes you to the ADDITIONAL SETUP screen.
ADDITIONAL SETUP	Specify the ANALOG OUTPUT and LOGGING time.
ANALOG OUTPUT	Set an analog voltage range for the output.
LOGGING	Choose intervals for logging data.

The following pages contain descriptions of the **SETUP** options.

SAMPLE TIME SETUP I SAMPLE TIME

Select a sample time in seconds for the on-screen graph. Press the **SAMPLE TIME** button to scroll through the settings. Sample Time choices are 1, 2, 3, 4, 5, 6, 10, 12, 15, 20, 30, and 60 seconds. If you intend to gather data for long periods of time, use the longer sample times to reduce the number of data files.

PUMP SETUP I PUMP

Select one of the following vacuum pump settings:

Pump Setting	Description
ON AFTER WARMUP	Turns on the pump. Message displays during the warm-up process.
ON	Turns on the pump valve. Message only displays when warm-up is complete.
OFF	Turns off the pump valve.

Note: You can toggle between the **ON** and **OFF** settings.

INLET MODE SETUP | INLET MODE

Set the inlet flow. Press the **INLET MODE** button to toggle between the inlet flow choices:

Inlet Mode Setting	Description
0.6 L/min	When the inlet flow is set to 0.6 L/min the transport flow is turned off and inlet flow is equal to the aerosol sample flow.
1.5 L/min	When the inlet flow is set to 1.5 L/min, the transport flow is turned on and an additional 0.9 L/min of flow is drawn into the inlet. This higher transport flow can reduce the loss of very small particles in tubing external to the GP-WCPC.

SET TIME SETUP | SET TIME

Select the date (year, month, and day) and time (hour, minute, and second) for data collection.

To set the date and time, follow these instructions:

1. Touch the screen option you wish to change. In the screen below, the Year is active (indicated by the line below the number) and ready to be changed.




2. Use the ▲ ▼ arrows to scroll through the different settings.
3. Touch **BACK** to return to the previous screen when you have made your choices.

NETWORK SETUP | NETWORK SETUP | NETWORK


Specify the network settings. The **NETWORK** button toggles between the settings **STATIC** and **DHCP** (shown in the screen below).

Note: *If the network settings have been selected, they are displayed, otherwise, they are blank.*



The screenshot shows a blue-themed interface titled "NETWORK SETUP". At the top right is a "HOME" button. Below the title is a "NETWORK" button, and to its right, the text "DHCP" is displayed. To the right of "DHCP" is a "BACK" button. Below these are three input fields: "ADDRESS", "MASK", and "GATEWAY", all of which are currently blank. At the bottom right is a "MORE" button.

On this screen, only the network setting has been specified.




The screenshot shows the same "NETWORK SETUP" interface. The "NETWORK" button is now highlighted, and the text "STATIC" is displayed to its right. The "BACK" button remains. The "ADDRESS" field now contains the value "192.168.10.201", the "MASK" field contains "255.255.255.0", and the "GATEWAY" field contains "192.168.10.1". The "MORE" button is still present at the bottom right.

On this screen all network settings have been specified.


ADDRESS SETUP | NETWORK SETUP | ADDRESS

Specify an IP address for your network. To set the IP Address, follow these instructions:

1. Press the numbers on the on-screen keypad.



2. When you have selected all the numbers, press **ENTER**. The IP Address is now recorded and displayed on the screen.



3. Press **BACK** to return to the Network setup screen where the IP address is now displayed.

MASK SETUP | NETWORK SETUP | MASK

Specify the network mask.

Note: *The Mask must match the size of your network. A typical setting is 255,255,255.0 for a small network.*

To set the Mask, follow the instructions for using the onscreen keypad to set the IP Address.

GATEWAY SETUP | NETWORK SETUP | GATEWAY

Specify the network gateway device. To specify the Gateway, follow the instructions for using the onscreen keypad to set the IP Address.

ANALOG OUTPUT SETUP | NETWORK SETUP | MORE | ADDITIONAL SETUP | ANALOG OUTPUT

Set the function of the analog output. The analog output port is located on the back of the instrument and provides a 0 to 10V output signal and can be scaled for the user application. Press the button to scroll through the options. Settings are 1.00, 100, 1000, 1.0 E⁴, 1.0 E⁵, 1.0 E⁶ #/cm³ FS, **LOG OUTPUT** (Logarithmic output), **SMPS MODE**, and **STATUS OUTPUT** (where a normal Status Output is 0. Abnormal output is 5V).

LOGGING SETUP | NETWORK SETUP | MORE | ADDITIONAL SETUP | LOGGING

Choose intervals for logging data to the Flash Memory Card. Logging options are either one hour, or one day. Press the button to toggle between the options.

TOTAL Screen


Pressing the **TOTAL** button on the home screen takes you to the **TOTALIZER** screen. The screen displays the following information:

- Current particle concentration in #/cm³.
- Number of accumulated particles.
- Sample time in seconds.
- Volume based on flow rate and sample time.

This option is useful for manually measuring concentration over a period of time.

There is a toggle button at the bottom of the screen. When you choose **TOTAL** from the Home screen, the toggle button displays **CLEAR TOTALIZER**. When you press **CLEAR TOTALIZER**, the button displays **START TOTALIZER**.

Note: If you go to another screen on the display, the **TOTALIZER** continues to run. It can only be stopped by pressing **STOP TOTALIZER**.



CHAPTER 6

Technical Description

The Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC) is a continuous-flow condensation particle counter that detects particles down to 5 nm at a sample flow rate of 0.6 L/min. This section describes the function of the GP-WCPC, its subsystems and its components. A discussion of operation theory and history is given first.

Theory

The GP-WCPC acts very much like an optical particle counter. However, the particles are first enlarged by a condensing vapor to form easily detectable droplets. The science, therefore, focuses on how to condense the vapor onto the particles. Portions of the following discussion are taken from a paper by Keady, et al. [1986].

In *heterogeneous* condensation, the vapor surrounding particles reaches a certain degree of supersaturation and begins to condense onto the particles. In *homogeneous nucleation* or *self-nucleation*, supersaturation is so high that condensation can take place even if no particles are present because molecules of the vapor form clusters (nucleation sites) due to the natural motion of the gas and attractive van der Waals forces. The GP-WCPC operates below the supersaturation ratio to avoid homogenous nucleation.

The degree of supersaturation is measured as a saturation ratio (P/P_s), which is defined as the actual vapor partial-pressure divided by the saturation vapor pressure for a given temperature:

$$\text{supersaturation} = \frac{P}{P_s}$$

For a given saturation ratio, the vapor can condense onto particles only if they are large enough. The minimum particle size capable of acting as a condensation nucleus is called the *Kelvin diameter* and is evaluated from the following relationship:

$$\text{saturation ratio} = \frac{P}{P_s} = \exp \frac{(4\gamma M)}{\rho R T d}$$

where γ = surface tension of the condensing fluid
 M = molecular weight of the condensing fluid
 ρ = density of the condensing fluid
 R = universal gas constant
 T = absolute temperature
 d = Kelvin diameter

The higher the saturation ratio, the smaller the Kelvin diameter.

For a curved liquid surface, such as the surface of a droplet, the actual saturation vapor pressure is greater. The smaller the droplet, the easier it is for the vapor molecules to escape the liquid surface. The Kelvin diameter defines the critical equilibrium diameter at which a pure droplet is stable (there is neither condensation nor evaporation). Liquid particles with diameters smaller than the critical equilibrium diameter will evaporate and larger particles will grow even larger by condensation. The larger particle will grow until the vapor is depleted, causing the saturation ratio to fall until it is in equilibrium with the particle droplet. The lower size sensitivity of the counter is determined by the operating saturation ratio.

History

In 1979, TSI introduced the world's first single-particle-counting condensation particle counter. The Model 3020 was a continuous-flow, diffusional, alcohol-based, thermal-cooling CPC (Bricard et al. [1976], Sinclair and Hoopes [1975], Agarwal and Sem [1980]). In an alcohol-based CPC the air sample is saturated with alcohol vapor when it passes over a heated pool of liquid alcohol. The vapor-saturated air stream flows into a cold condenser tube where the air is cooled by thermal diffusion. The alcohol condenses onto the particles and the droplets grow to approximately 3 to 5 micrometers. The droplets are then counted by a single-particle-counting optical detector.

The Models 3010, 3025, and 3022 were butanol based CPCs introduced in the late 80s and were replaced by Model 3771, 3772, 3775, and 3776 in 2005. A hand-held, battery powered isopropyl alcohol CPC (Model 3007) was introduced in 2004.

Continuous-flow, diffusional, water-based CPCs (WCPCs) were developed between 2003 and 2006 (TSI Model 3781, 3785, and 3786 WCPCs). Using a patented technology* from Aerosol Dynamic Inc., an aerosol sample is drawn continuously through a cooled conditioner into a heated condenser. In the condenser, water vapor diffuses to the centerline faster than heat is transferred from the warm walls, producing supersaturated conditions for water vapor condensing onto the particles.

In 2010, the Model 3783 was developed specifically for measuring high concentrations in single-count mode for environmental monitoring. Also in 2010, the Model 3785 was replaced by the Model 3787, and the 3786 was

*U.S. Patent No. 6,712,881

replaced by the Model 3787. These new instruments have significant improvements to increase reliability and add features.

Models 3772, 3775, 3776, 3785, 3786, 3787, and 3787 can be used as components of a Scanning Mobility Particle Sizer™ (SMPS™) Spectrometer (TSI Model 3936). The SMPS™ provides high-resolution submicron-aerosol size-distribution measurements.

Design of the Model 3787

Submicrometer particles are drawn into the particle counter and enlarged by condensation of a supersaturated vapor into droplets that measure several micrometers in diameter. The droplets pass through a lighted viewing volume where they scatter light. The scattered-light pulses are collected by a photodetector and converted into electrical pulses. The electrical pulses are then counted and their rate (live-time corrected) is a measure of particle concentration.

The basic instrument consists of three major subsystems: the sensor, the microprocessor-based signal-processing electronics, and the flow system. The sensor and the flow system are described below.

Sensor

The sensor contains a conditioner, a growth tube, and an optical detector (shown schematically in Figure 1-2). The sensor grows the sampled aerosol particles into larger droplets that are detected optically.

The sample flow is cooled with a thermoelectric device in the conditioner. The vapor passes into the growth tube where it becomes supersaturated and condenses onto the aerosol particles (acting as condensation nuclei) to form larger droplets. The droplets pass through a nozzle into the optical detector.

The sensor's optical detector is comprised of a laser diode, collimating lens, cylindrical lens, elliptical mirror, and photodiode detector. The laser and collimating lens form a horizontal ribbon of laser light above an aerosol exit nozzle. The collection mirror focuses the light scattered by the droplets at a 90° angle (side scatter) onto a low-noise photodiode. The main beam is blocked by a light-stop in the back of the sensing chamber. A reference photodiode is used to maintain constant laser power output. The surface temperature of the optics housing is maintained at a higher level than the growth tube to avoid condensation on the optical surfaces.

The Model 3787 operates in single particle count mode up to 3×10^5 particles/cm³. Rather than simply counting individual electrical pulses generated by light scattered from individual droplets, the Model 3787 uses a continuous, live-time correction to improve counting accuracy at high particle concentrations. Live-time correction occurs when the presence of

one particle obscures the presence of another particle creating an undercounting error that results in dead time.

Pulse Height

The Model 3787 contains an electronic subsystem for monitoring the amplitude (voltage height) of the particle pulse generated by the optical detector. The actual amplitude of the pulse does not affect the particle counting performance as long as it is large enough to intercept the preset discriminator threshold. Typical pulse amplitudes (1 to 2 volts) are 10 to 40 times higher than the discriminator level which is typically 20 times higher than the RMS noise level of the photo-detector electronics. This large magnitude of “signal-to-noise” margin provides robustness in performance in the optical detection of droplets.

Under normal operating conditions, the pulse amplitude decreases with increasing particle concentration. As particle concentration increases, depletion effects within the growth tube cause the nucleated droplets to grow to smaller sizes than they would at lower particle concentrations.

Note: *The droplet size has been reduced in this instrument compared to those of previous generations—reducing the variation in pulse amplitude with respect to particle concentration to about 2:1 over the concentration range of the instrument.*

Changes in optical alignment, laser power, or optical cleanliness can all reduce pulse amplitude; therefore, the pulse amplitude is a good indicator of the “health” of the GP-WCPC. A peak-sense and hold circuit within the Model 3787 measures the pulse amplitude of 50 particles/sec. The average pulse amplitude is displayed both numerically and in a bar graph on the Status screen, and is also included in the data retrieved from the digital interfaces. The limitation of the Pulse Height indication is that it requires the presence of at least 50 particle pulses/sec to provide information. The Pulse Height fault status indication is displayed for particle concentrations over 10 #/cm³ with a pulse height of <350 mV.

Flow System

Refer to Figure 6-1 while reviewing the instrument flow information.

The Model 3787 GP-WCPC has two user-selectable sample air flow modes controlled by critical orifices.

Orifice	Description
0.6 L/min aerosol sample flow mode	Carries the aerosol to be sampled. Used for ambient sampling and systems with short tubes.
1.5 L/min transport flow mode	A user-selectable flow rate used to reduce particle losses in external plumbing by reducing the transit time.

Problems with the aerosol flow can be detected by monitoring the pressure drop across the nozzle and verifying that the critical orifice pressure is maintained.

Critical Flow

To achieve the 0.6 L/min sample flow through the sensor, an orifice is used (operated at the *critical pressure ratio*) to provide a *critical flow*. Critical flow is very stable and is a constant volumetric flow, assuring accurate concentration measurements despite varied inlet pressure.

The critical pressure ratio is found by dividing the absolute pressure downstream of the orifice P_D , by the absolute pressure upstream of the orifice P_U . This ratio must be below 0.528 for air.

$$\text{Critical pressure} = \frac{P_D}{P_U} \leq 0.528$$

The following pressure values are displayed on the Status screen and can affect the GP-WCPC monitor flow.

Pressure Value	Description
Vacuum	The vacuum pressure
Inlet Pressure	The inlet pressure.
Nozzle Pressure	The differential pressure across the Nozzle and filter.

Temperature Control

The temperatures of the conditioner, growth tube, and optics are nominally maintained at 20°C, 60°C, and 60°C, respectively, with specified ambient temperatures in the operating range of 10 to 35°C. Temperatures are controlled through feedback circuits on the main electronics board and are displayed on the Status screen on the front-panel display.

Note: *For ambient temperatures outside the instrument operating range, the instrument temperature performance may not be maintained. Moderate increases in conditioner temperature will raise D_{50} a small amount.*

Inlet Pressure Measurement

With the built-in vacuum pump, the instrument is capable of operating at barometric pressures from 75 to 105 kPa. The inlet pressure is measured by an absolute pressure sensor and is equal to the barometric pressure if no inlet restriction is present. When the vacuum pump is turned on, the inlet pressure is recorded. The difference between the recorded pressure and the inlet pressure is the inlet gauge pressure. The inlet gauge pressure is controlled by external connections to the inlet—if this value exceeds the maximum specified value, the pump is switched off. The pump automatically switches on one minute after the gage pressure limit is no longer exceeded.

The Inlet Pressure reading is displayed on the Status screen on the front-panel display.

Water Removal System

The Model 3787 GP-WCPC has a water separator and ejection system to remove water from the vapor stream exiting the optics assembly. The water separator condenses the water vapor and then the collected water is ejected through the **WATER EXHAUST** port on the back panel and away from the internal flow control orifices. The water bottle is designed to allow the small amount of expelled water to be recycled by inputting it back into the recycle fill bottle.

Internal Clock

The clock used in the 3787 is a Quartz crystal component embedded in the microprocessor. The accuracy is on the order of about a second per day, but time drift during long periods of data logging is possible. If a higher level of time accuracy is needed, one of the following options should be implemented:

1. Use Aerosol Instrument Manager® software as the data collection tool. The software can be configured to synchronize the 3787 with the computer clock once per day.
2. Send a serial command to the instrument once per day to reset the 3787 clock to synchronize with the data collection tool.
3. If collecting data via the USB stick, reset the clock on the instrument as needed.

Counting Efficiency and Response Time of the Model 3787

The Model 3787 GP-WCPC has a sharp lower detection curve with a D_{50} of 8 nm. D_{50} is defined as the particle diameter at which 50% of particles are detected. The curve fit shown in Figure 6-1 details the particle detection efficiency.

The particle concentration measured by the particle counter is the total number concentration of all particles that the Model 3787 can detect. This measurement provides no size differentiation and it is not corrected using the Model 3787 counting efficiency curve.

The GP-WCPC monitor has a fast response time. T_{95} , defined as the time it takes for the GP-WCPC reading to reach 95% of a concentration step change, is <1.0 sec. Figure 6-2 shows the response time curves to a step change in concentration based on the average of three GP-WCPCs. The ~700 millisecond time to a 95% response in concentration in high flow rate mode includes a flow rate based pipe delay. Under normal operation with constant

flow, the traditional rise time (10 to 90%) is <300 milliseconds. The time constant (τ) of the Model 3787 is ~130 milliseconds.




Figure 6-1
Detection Efficiency Curve of Model 3787 General Purpose Water-based Condensation Particle Counter




Figure 6-2
Response Time of Model 3787

(This page intentionally left blank)

CHAPTER 7

Particle Counting

This chapter discusses particle counting and particle count measurements performed using the Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC).

Concentration data from the GP-WCPC can be viewed on the **HOME** screen and on the **STATUS** screen. The concentration value displayed on the **HOME** and **STATUS** screens is calculated based on one second of particle count, live-time, and flow data based on the following formula:

$$\text{Partical Concentration} = \frac{n}{Q \times t}$$

where

n = The number of particles counted

Q = Aerosol Sample flow rate ratio (nominally 0.60 L/min).

t = sample live-time in seconds.

The displayed value is updated each second, but the actual sample time used in the calculation is always less than one-second because the dead-time for each particle pulse detected reduces this value. At concentrations below 1,000 #/cm³, the displayed value is based on a ten-second running average of particle counts and sample time.

The concentration graph on the **HOME** screen provides a plot of particle concentration based on the sample time setting in the **SETUP** screen. Each plotted point is based on the sum of particle counts, sample live-time, and an average sample flow over the selected period. Sample periods from 1 to 60 seconds can be selected and the graph time scale will be adjusted accordingly. This value is also used in the data logged to a connected USB Flash drive or from data collected from the serial interfaces based on the Set Mode (SM) command.

Concentration data can also be collected using the Totalizer mode (on the **TOTALIZER** screen). The Totalizer mode is used to measure low particle concentrations. It can also be used to collect concentration data over a specific, manually-controlled, sample period. The Totalizer accumulates the particle counts, sample live-time, and total sample volume. The sample volume is based on the measured sample (capillary) flow of the instrument during the time the Totalizer is operating.

Total Count Accuracy

At very low concentrations, the accuracy of the measurement in the single-particle-counting mode is limited by statistical error. If the total number of particles counted in each time interval is very small, the uncertainty in the count is large. The relative statistical error of the count σ_r is related to the total count n by

$$\sigma_r = \sqrt{n}.$$

In Totalizer mode, the accuracy of the concentration is increased by sampling for a longer period and counting more particles. The concentration is displayed on the front panel in Totalizer mode and is calculated by:

$$\text{concentration} = \frac{\text{total counts}}{\text{volume of aerosol flow in the sensor}} = \frac{n}{Q \times t}$$

where

Q = Sample (capillary) flow rate ration (nominally 0.30 L/min).

t = sample live-time in sec.

The number of particles in the measured sample is one of the limiting factors of how low a particle concentration can be precisely determined. To calculate low particle concentrations, the Totalizer uses the elapsed time as the sample time in the above calculation.

The formula for this statistical precision is:

$$\sigma_N = \frac{\sqrt{N}}{N} \times 100\%$$

where:

σ_N = is the relative standard deviation in percent

N = is the number of particle counts in the sample

For a sample of 10,000 particles, the statistical precision is 1% (greater accuracy than that of the instrument). At 100 particles, the statistical uncertainty increases to 10% and becomes a significant factor in determining the aerosol concentration. The Totalizer allows for increased statistical precision at low particle concentrations through the use of longer sample times.

Live-Time Counting

Coincidence occurs when more than one particle occupies the optical sensing region simultaneously. The optical detector cannot discriminate between the particles and multiple particles are counted as a single particle. At higher particle concentrations, particle coincidence begins to have a significant impact on the measured concentration.

The GP-WCPC monitor corrects for coincidence continuously with the instrument electronics performing a “live-time” correction.

Live-time refers to the time between electrical pulses. This is the total measurement time interval minus the time during which the counter is disabled with one or multiple particles in the optical sensing volume (the dead time). The dead time should not be included in the sample time since only the particles already in the viewing column can be counted. The actual particle concentration therefore equals the number of counted particles divided by the live-time (actual sample time) and the aerosol flow rate.

To measure live-time, a high-speed clock and accumulator are used. The accumulator adds up the live time and the counter adds up pulse counts. The particle concentration is then calculated by

$$C_a = \frac{\text{number of counted particles}}{\text{accumulated live - time}} \times \frac{1}{\text{aerosol flow rate}}$$

Note: At concentrations $>2.5 \times 10^5$ particles/cm³, the status reads **Over Range**. If this occurs, the Model 3787 is outside of the concentration operating range and the number concentration of particles shown on the display may be inaccurate.

Concentration Measurement

The GP-WCPC can report particle concentration values in the following ways:

- On the front-panel display.
- On the Totalizer display.
- Using the data communications ports.

Particle concentration is presented as particles per cubic centimeter (p/cm³). The following parameters are important for calculating particle concentration:

- The number of particle pulses counted (measured internally by the Model 3787).
- The sample time (measured internally by the Model 3787).
- The sample flow rate (nominally 0.6 L/min).

The basic calculation for the number of particles per volume of air is:

$$\text{Concentration} = \frac{N}{Q \times t}$$

where:

Concentration is the particle concentration in #/cm³

N is the number of particle counted

t is the sample time

Q is the sample flow rate in cm³/second

The number of particles in the measured sample is one of the limiting factors of how low a particle concentration can be precisely determined. To calculate low particle concentrations, the Totalizer uses the elapsed time as the sample time in the above calculation.

The formula for this statistical precision is:

$$\sigma_N = \frac{\sqrt{N}}{N} \times 100\%$$

where:

σ_N is the relative standard deviation in percent

N is the number of particle counts in the sample

For a sample of 10,000 particles, the statistical precision is 1% (greater accuracy than that of the instrument). At 100 particles, the statistical uncertainty increases to 10% and becomes a significant factor in determining the aerosol concentration. The Totalizer allows for increased statistical precision at low particle concentrations through the use of longer sample times.

When a particle enters the optical viewing volume and is being detected, no other particles can be counted. As the particle concentration increases, the amount of time blocked by the presence of particles becomes significant. If the particle concentration were computed using elapsed time, the value would be under-reported; therefore, the actual sample time needs to be corrected for this blocked or dead time.

To adjust for this particle "coincidence" effect, the Model 3787 measures the "dead time" resulting from the presence of particles in the viewing volume and subtracts it from the sample time. This sample "live-time" value is used in place of the elapsed sample time for the concentration calculations for the primary display when not using the Totalizer.

At very high concentrations, the dead-time value grows and the adjustment becomes large. Single particle events may not even be detected since particles are nearly continually in the measurement viewing volume and the accuracy of the "live-time" measurement begins to diminish. Under extreme overload conditions the display will show an "OVER" annotation or a concentration of $9.99e^5$ particles/cm³.

During operation, the GP-WCPC collects single particle counts and dead-time corrected sample time every tenth of a second. The concentration value reported on the front-panel display is updated each second. It uses data collected over the previous second of elapsed time to calculate concentration. If the concentration is <1000.0 particles/cm³, a 10-second running average of particle count data is used to calculate the displayed value.

Concentration data is also available from the data communications ports and it is "aggregated" or summed from each tenth-second measurement with programmable sample periods from 0.1 second to 600 seconds.

Totalizer Mode

The Totalizer mode counts the number of particles in a given time period. This mode is used primarily to improve counting resolution at very low particle concentrations, but it can also be used to take an average over a user-specified time period.

The time, number of counts, accumulated sample volume, and particle concentration are shown on the display. The time is the actual sample time and is shorter than the elapsed time (beginning when the Totalizer is started).

The Totalizer automatically stops when 3600 seconds of sample time have been accumulated.

(This page intentionally left blank)

CHAPTER 8

Computer Interface, Commands, and Data Collection

This chapter provides information about the computer interface, communications information, and data collection for the Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC). Information about using a Flash Drive is also provided.

Analog Inputs

The Model 3787 GP-WCPC can monitor the analog voltage from an external source via the analog input BNC connector on the back panel (labeled Analog In). The input voltage range for these ports is 0 to 15V. Analog voltages can be displayed together with concentration data on the LCD display and saved to the removable flash drive or a computer. Voltages measured from a device connected to the Analog Input can be correlated to particle concentration in real time.

Amplification of external signals may be needed and supplied by the user to bring low voltage signals to the appropriate 0 to 15 V range for best resolution.

Analog Output

During normal operation of the Model 3787 GP-WCPC, the **Analog Out** port provides an analog 0 to 10 V signal proportional (linear or log) to particle concentration. This particle concentration is corrected for coincidence and tracks the displayed concentration.

Pulse Output

Pulse Out provides a 5-volt (50-ohm termination) digital pulse for each particle detected and is a way to get raw count information. This enables you to use external counting electronics hardware to acquire particle count data for special applications. The width of the pulse depends upon both the shape of the photo detector pulse and the trigger-level of the pulse threshold. The pulse width for a single particle pulse is typically 0.8 μ s. To provide accurate pulse counts, *use a counter that is capable of counting pulses with a width of 500 nanoseconds or less.*

Particle concentrations that are calculated based on the particle counts from the Pulse Output are *not live-time corrected* for particle coincidence. Thus, when particle concentration is high, the concentration will be lower than the displayed concentration. Appropriate coincidence correction should be applied when pulse output is used for high concentration measurements.

Computer Interface

The GP-WCPC provides four interfaces to allow for flexible data collection and instrument control. This section of the manual includes information about the following data interfaces:

- Ethernet. An Ethernet port used for remote connections via a local (LAN) or extended (Internet) network. The Ethernet connection provides the same data protocols and firmware commands as provided by the USB or Serial connections. The Ethernet communication allows you to monitor the GP-WCPC status (including particle concentration) from a remote location.
- Flash Drive. A flash drive port used to log data to a USB flash drive (in hourly or daily files) without a host computer.
- USB: A USB 1.1 connect to a local computer running data collection and analysis software (such as the TSI Aerosol Instrument Manager[®] software included with the instrument), or a terminal emulation program.
- RS-232 (Serial): A standard 9-pin RS-232 serial connection used to connect to a local computer running data collection and analysis software (such as the TSI Aerosol Instrument Manager[®] software included with the instrument), or a terminal emulation program.

The USB port enumerates as a virtual COM port under Windows[®] operating system, making the USB and serial ports act in a similar manner to the external software. Serial commands are sent to and from the computer to monitor instrument status information, to retrieve and monitor data, and to provide a variety of control functions. When USB or RS-232 serial communications are used with the Aerosol Instrument Manager[®] software, the computer automatically recognizes the GP-WCPC as a TSI instrument. Additional information on communications can also be found in the Aerosol Instrument Manager[®] software manual.

Although four interfaces are provided, you can only use one at a time. The Serial and USB data interfaces share a common communications channel to the GP-WCPC microcontroller. Data input to the GP-WCPC from the Serial interface is exclusive from input via the USB interface.

Communications can be received from the Serial interface until a connection is linked to the USB port. When the link is established, communications can be received via the USB port but not from the Serial port. When the USB link is terminated, the Serial port can be used.

More details about these interfaces can be found on the following pages.

Ethernet

The Ethernet port on the General Purpose Water-based Condensation Particle Counter (GP-WCPC) can provide system status information or instrument control over a network. In the instructions below, the client is used. Please note that Telnet feature is not included with Windows Vista® or Windows 7 operating systems and it must be enabled to be used.

To enable Telnet in Windows® 7 operating system, follow these instructions:

1. From the **Start** menu, choose **Control Panel** and then choose **Programs and Features**.
2. Choose **Turn Windows features on or off**.
3. Choose **Telnet Client** and then click **OK**. A dialog box appears confirming the installation of new features.


To monitor system status using the Telnet client, follow these instructions:

1. Insert an Ethernet cable into the Ethernet port on the back panel of the GP-WCPC and connect the cable to your network or a personal computer.
2. On the GP-WCPC home screen, choose **SETUP** then choose **MORE** to view the **NETWORK SETUP** screen.
3. On the **NETWORK SETUP** screen, choose **ADDRESS** and enter a static IP address for this unit that is available on your network. Alternately choose **NETWORK** and select **DHCP**. If your network has a DHCP server, a dynamic address will be selected for you in a few seconds.
4. If you are using a personal computer, from the **Start** menu, choose **Run** then type the command **telnet xx.xx.xx.xx** where **xx.xx.xx.xx** is the IP address determined in step 3.
5. A console screen appears which allows direct entry of firmware of commands.

To test communication between the personal computer (or your network) and the GP-WCPC, follow these instructions:

1. From the Start menu, choose **Run**, type **cmd**, and press **Enter**.

2. In the resulting window type **ping xx.xx.xx.xx** where **xx.xx.xx.xx** is the IP address determined in step 3 above.
3. The response shows the response from the instrument if the network connection is valid as shown in the figure below.



```
C:\WINDOWS\system32\cmd.exe
C:\>ping 192.168.10.132

Pinging 192.168.10.132 with 32 bytes of data:

Reply from 192.168.10.132: bytes=32 time<1ms TTL=128
Reply from 192.168.10.132: bytes=32 time<1ms TTL=128
Reply from 192.168.10.132: bytes=32 time<1ms TTL=128
Reply from 192.168.10.132: bytes=32 time<1ms TTL=128

Ping statistics for 192.168.10.132:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\>
```

Figure 8-1
Screen Showing Valid Network Connection

Flash Drives

The GP-WCPC can store particle concentration data and analog input data to a flash drive inserted into the flash drive port. Only one flash drive port at a time can be used.

Note: *Some Flash drives larger than 16 Gigabytes may not be recognized.*

To insert a flash drive, follow these instructions:

1. Plug the flash drive into the USB flash drive port on the back panel of the GP-WCPC monitor.
2. Check the Home screen. You should see a **START** button displayed beneath the other home screen buttons. If you do not see this button, check that your flash drive is inserted correctly. You should also see a status message beneath the button. This message reads **Mem Stick** until you begin data collection.
3. Press **START**. The status message changes to **Logging** and the button displays **STOP**. When you press **START**, a directory named **3787** is created on the flash drive. The data files created within that directory contain either one hour or one day of data (depending upon the **SAMPLE TIME** you chose on the **SETUP** screen), unless you press **STOP** to discontinue the data logging.

Note: *The **SAMPLE TIME** cannot be changed while data is being logged. You must stop logging data first.*

4. Press **STOP** to discontinue data logging at any time.

Note: *Do **not** remove the flash drive while logging data.*

Flash Memory Data Files

The data is stored in files with the "dat" extension and a new file is created either every day or every hour (depending upon the Logging selection you have made). If you stop data collection at any time, the current data file is saved even if it contains less than one hour/day of data. These data files can be imported to Aerosol Instrument Manager[®] software.

Every time you begin a new run, a unique file is created. Each data file has the following format:

Filename	yymmddxx, where yy is the year (no leading zero), mm is the month (1-12), dd is the day of the month, and xx is a sequence number for the day (01-99). Example: 12110601.DAT where 12 is the Year, 11 is the month, 06 is the day, 01 is the file number and .DAT is the extension.
LINE 1	"TSI CPC DATA VERSION 3"
LINE 2	Time stamp for the file: yy/mm/dd, hh:mm:ss where yy is the year, mm is the month, dd is the day of the month, hh is the hours, mm the minutes, and ss the seconds.
LINE 3	Data average period (sample time intervals) in seconds.
LINE 4	Dead-time correction factor, flow calibration constant (mL/min).
LINE 5	Instrument model number, firmware version number, serial number.
LINE 6	Header descriptions.
LINE 7	First data record.
LINE 8	Second data record.

Example of data record:

```

TSI CPC DATA VERSION 3
1268228469,2012/3/10,13:41:09
60
1.03,600
Model 3787 Ver 1.00 S/N 123456
"Date","Time","Concentration","Count","Live-Time","Flow","Abs
Press"," Analog In","Pulse Height"," Pulse STD","Status Flags"
2012/3/10,13:41:57,2.15e4,2522183,58.62,300,970,0.00,567,600,0
2012/3/10,13:41:57,2.32e4,2719488,58.51,300,970,0.00,607,595,0
2012/3/10,13:42:57,2.15e4,2530791,58.62,300,970,0.00,587,609,0
2012/3/10,13:43:57,2.13e4,2505886,58.63,300,970,0.00,581,615,0

```

Data fields include:

- Date
- Time
- Particle Concentration ($\#/cm^3$)
- Raw Particle Counts
- Live-time (seconds)
- Flow (capillary flow in cm^3/min)
- Absoluter Pressure (mbars)
- Analog Input (V)
- Pulse Height average (mV)
- Pulse Height Standard Deviation
- Status flags.

Select the Sample Time (the period over which data is collected and reported) from one of the following choices: 1, 2, 3, 4, 5, 6, 10, 12, 15, 20, 30, or 60 seconds. Data is collected internally 10 times/second and is averaged over the selected sample time. The average is displayed on the graph and can be saved to the flash drive. Data is saved to the flash drive every 10 seconds or at the rate of the data averaging period if it is longer than 10 seconds. The data averaging period is the same as the Sample Time setting. Once the data is being logged to the flash drive, the Sample Time setting cannot be changed.

IMPORTANT

If power is lost at any time, the instrument should continue data logging when the power is returned. The data files created will have the extension **.rdt** so that the previous files are not overwritten.

USB

USB communications are provided with the GP-WCPC for use with the supplied Aerosol Instrument Manager[®] software. USB driver software must be installed on the host computer. For Windows[®] operating systems the drivers may be downloaded from the USB chip manufacturer's site at: <http://www.ftdichip.com/Drivers/VCP.htm>

To install the USB driver, follow these instructions:

1. Find the appropriate driver for the host computer's operating system.
2. Download the driver to the host computer.
3. Extract (unzip) the driver to a blank folder.
4. Connect the computer to the GP-WCPC USB port.
5. Follow the **Add New Hardware** wizard steps and browse to the folder containing the extracted driver. If the wizard does not start, use the **Add Hardware** function on the Control Panel.

When the USB driver is loaded, the operating system recognizes the GP-WCPC as a new serial device. In Microsoft Windows® operating system this is a new port (such as COM2 or COM6). If it is not obvious which COM port is being used, you can check in the computer's Device Manager. To check which COM port is being used, follow these instructions:

1. Open the **Control Panel** and choose **System**.
2. In the **System Properties** dialog box, choose the **Hardware** tab and then click **Device Manager**.
3. In the **Device Manager** dialog box, click the + sign next to **Ports (COM & LPT)**. The USB Serial Port indicates in parenthesis which COM port is being used.

Connect the supplied USB cable to the GP-WCPC and a computer running the Windows®-based operating system and the Aerosol Instrument Manager® software. In the Aerosol Instrument Manager® software, double-click the correct COM port and the data is displayed in real time (depending upon the sample time you have selected).

Refer to the Aerosol Instrument Manager® software manual for specific system requirements, including operating system version.

RS-232 Serial Communications

The communications ports are configured at the factory to work with RS-232-type devices. RS-232 is a popular communications standard supported by many mainframe computers and most personal computers. The Model 3787 GP-WCPC has one 9-pin, D-type subminiature connector on the back panel (labeled Serial).

Table 8-1 lists the signal connections.

Note: *This pin configuration is compatible with the standard IBM® personal computer serial cables.*

Table 8-1
Signal Connections for RS-232 Configurations

Pin Number	RS-232 Signal
2	RXD (Input to GP-WCPC)
3	TXD (Output from GP-WCPC)
5	GND

An external computer is connected to the Serial 1 or USB ports for basic instrument communications and when Aerosol Instrument Manager® software is used.

Communications Parameters

All serial communications with the GP-WCPC are accomplished using the following communications parameters:

- Baud Rate: 115,200
- Bits/Character: 8
- Stop bits: 1
- Parity: None

All data communications are performed through ASCII-based character codes.

All multi-field responses are comma separated values (CSV).

All input commands and output responses are terminated with a carriage return.

All input line feeds are ignored.

Terminal Communications

When you have made a Serial or USB connection between the GP-WCPC and host computer, you can use Aerosol Instrument Manager[®] software or a terminal emulation program to communicate with the GP-WCPC. You can choose from the following terminal emulation programs:

- Tera Term—a free terminal emulator for Microsoft Windows[®] operating systems.
- HyperTerminal—included with most Microsoft Windows[®] operating systems.

You should set up the terminal emulation software so that incoming carriage returns are translated into carriage return line feed sequences and therefore do not overwrite the previous line of data. Also, consider enabling local echoing of characters so that data typed on the keyboard is displayed on the screen.

If you press the **Enter** key when the terminal emulation software is connected and running, you will see an **ERROR** response from the GP-WCPC in the terminal emulation software. This is because, although the GP-WCPC and computer are communicating, the command is not understood. This error message can be ignored—it is only used for testing the connectivity. When data is being reported to the screen of the terminal emulation software, the data can be cut and paste into a file, or the software's data logging capabilities can be used to capture data. Data in the comma-delimited format can be imported into programs such as Microsoft Excel[®] spreadsheet software for analysis and graphing.

Appendix B, "[Firmware Commands](#)", describes the commands that control the operation and data reporting options for the GP-WCPC.

Aerosol Instrument Manager[®] Software

Aerosol Instrument Manager[®] software is supplied with the Model 3787 GP-WCPC. This program provides many useful data acquisition, display, processing and download functions used in particle measurement. Review the supplied Aerosol Instrument Manager[®] software manual for complete information on software functions.

Commands

It is important to note the following information about the commands and responses:

- Unless specified as binary-encoded, all commands and responses are sent or received as ASCII characters.
- All messages are terminated with a <CR> (0x0D) character.
- All linefeed (0x0A) characters are ignored and none are transmitted.
- Commands are case insensitive. The backspace character (0x08) deletes previous characters in buffer.
- Values enclosed by "<>" indicate ASCII characters/values sent/received. For example, <,> indicates the comma was sent or received via the communications channel.

The firmware commands are divided into the following categories:

Commands	Description
READ	Used to read parameters from the instrument (such as flow rate, pressure, temperature, etc.). READ commands can be identified by a leading "R".
SET	Set an internal parameter to the value(s) supplied with the command (supplied parameters are always delimited by a comma). SET commands can be identified by a leading "S". The instrument will reply to all SET commands with the string "OK"<CR>.

Note: When the instrument does not understand a command, it replies with the string "ERROR".

To use the firmware commands, a program capable of sending and receiving ASCII text commands can be used. A terminal program such as HyperTerm (supplied with Windows[®] operating system) is appropriate. To use HyperTerm, follow these instructions:

1. Connect to Serial 1 of the Model 3787.
2. Open the HyperTerminal program by selecting: **Start | Programs | Accessories | Communications | HyperTerminal**.
3. Enter a name for the connection, for example, TSI-3787.
4. Enter the communications (COM) port.

5. Enter the following port settings and click **OK**:
Bits per second: 115200
Data bits: 8
Parity: None
Stop bits: 1
Flow control: None
6. Under the settings tab, pick the **ASCII Setup** button and check the following boxes:
 - Send line ends with the feeds
 - Echo typed characters locally
 - Append line feeds to incoming line ends
 - Wrap lines that exceed terminal widths
7. From the **File** menu choose **Save As** and save the file to the desktop for easy access.
8. Close the program and start it again from the desktop. It should automatically open a connection to the instrument.
9. Type in firmware commands to communicate with the GP-WCPC. A list of firmware commands can be obtained from [Appendix B](#).


CHAPTER 9

Maintenance, Service, and Troubleshooting

This chapter describes recommended maintenance procedures and is intended to be used by a service technician with skills in both electronics and mechanics. Static preventative measures should be observed when handling any printed circuit board connectors.

Regular maintenance of the Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC) will help ensure years of useful operation, however the frequency of service depends upon the frequency of use and the cleanliness of the air measured.

If you need to contact TSI for assistance, please have the Model 3787 GP-WCPC close to the telephone when discussing the problem with a TSI technician.



WARNING

Procedures described below may require removal of the instrument cover. The instrument must be unplugged prior to service to prevent possible electrical shock hazard.



WARNING

Unplug the instrument prior to removing the cover to avoid potential of exposure to laser radiation.



Caution

Whenever performing service on internal components avoid damage to the GP-WCPC circuitry by not stressing internal wiring, through bumping, snagging or pulling. Also use electrostatic discharge (ESD) precautions:

- Use only a table top with a grounded conducting surface.
- Wear a grounded, static-discharging wrist strap

Removing the Cover

When removing the GP-WCPC cover to perform service or maintenance, follow the instructions below:

1. Read the warnings and cautions at the beginning of this chapter.
2. Unplug the instrument and remove the instrument cover by loosening the six side panel screws.
3. Lift the cover up.

Replacement Parts Kits

In addition to replacement parts found in your supplied accessory kit, additional replacement items are available from TSI to keep your GP-WCPC operating for many years. Parts are available in kits listed below in Table 9-1. Please contact your TSI representative for details and purchase of these items.

Table 9-1
Model 3787 GP-WCPC Maintenance and Replacement Kits

TSI Part No.	Name	Description
1187001	3787 Maintenance Kit	See Table 2-2 in Chapter 2 for details.
1180003	Wick kit 3787	Set of 12 Replacement Wicks (Growth Tube and Conditioner) 3787
1180008	Wick Cartridge	Replacement sleeve with wick installed
1183004	Critical Total Orifice, Exhaust Filter	Replacement filter for critical flow control orifice, critical transport flow orifice, and pump
1180004	Critical Flow Control Orifice 3787	3787 Replacement Critical Flow Control Orifice .011 inch
1180005	Critical Transport Flow Orifice 3787	3787 Replacement Critical Transport Flow Control Orifice .

Internal Instrument Components

Internal components are described in this section and identified in the photos below.




Figure 9-1
General Purpose Water-based Condensation Particle Counter Internal Components
(viewed from left side)




Figure 9-2
General Purpose Water-based Condensation Particle Counter Internal Components (viewed from right side).




Figure 9-3
General Purpose Water-based Condensation Particle Counter Internal Components
(viewed from above and front)

Optics Module

The optics module detects particle droplets from the growth tube. The optics module contains a laser, photodetector, and the optics, as well as the detector and optics circuit boards.

Vacuum Pump

The Model 3787 GP-WCPC contains an internal vacuum pump to draw air through the instrument.

Water System

The water separator removes water from the vapor stream coming from the optics head. This prevents water from condensing and blocking the flow orifices. Water is pumped from the separator by the water ejector pump.

The conditioner and growth tube have separate wicks, therefore the GP-WCPC contains two reservoirs. A sensor in the GP-WCPC engine opens a valve to allow intake of an appropriate amount of water from the reservoirs through the wick assembly openings. The figures below show the wick assembly.




Figure 9-4
Water-based Condensation Particle Counter Wick Assembly



Figure 9-5
Wick Cartridge, Growth Tube separated from Conditioner

The flow control orifices operate under vacuum from the internal pump. The flow on the upstream side is determined by the orifice diameter. Each orifice has a filter to remove particles from the water stream and protect the orifices.

Fans

Three internal fans cool the instrument; the cabinet fan cools the internal electronics, the conditioner fan dissipates the heat generated during cooling of the conditioner, and the water separator fan cools the heat sink associated with the thermo-electric devices.

Circuit Boards

The Model 3787 GP-WCPC contains the following circuit boards:

- Main board.
- Laser board.
- Detector board.

The main circuit board controls all the primary functions. Feedback circuits on the main electronics board, control the internal temperatures (displayed on the Status screen).

Changing the Filters

The Model 3787 GP-WCPC contains three filters mounted under the cabinet cover to clips on the side of the instrument, as shown in Figure 9-1. The filters should be replaced as part of the annual service.

To replace a filter, follow these instructions:

1. Turn off the power to the GP-WCPC.
2. Remove the instrument cover.
3. Remove the filter you are changing from its filter clip.
4. Noting the direction of flow, pull the tubing off both ends of the filter.

Note: Sometimes it is easier to push rather than pull. If a filter screen is present as shown in Figure 9-6, do **not** remove the Filter Screen.




Figure 9-6
Filter noting Direction of Flow

5. Attach the tubing to a new filter making sure the flow direction matches that of the filter you removed. The Filter Screen is in-line located after the arrow, as shown in Figure 9-6.
6. Push the filter into the filter clip.
7. Replace the instrument cover when you have completed your maintenance work.

Removing and Installing the Wick

The wick should be replaced after 700 hours of operation or every 3 months (8-hr/day operation). To replace a wick, follow these instructions:

1. With the GP-WCPC powered on, disconnect the water supply and operate the instrument with the pump on for two hours to dry the wick to be replaced. The wicks are difficult to remove when wet.
2. Disconnect power from the GP-WCPC.

3. Loosen the aerosol inlet jack-screw using the supplied 1/8" hex driver by slowly turning the screw. As you turn the screw, the inlet block and wick cartridge are pushed out of the instrument.




Figure 9-7
Inlet Jack Screw. Inlet Block Removal with the Hex Wrench




Figure 9-8
GP-WCPC Wick Cartridge from Inlet Assembly

4. Once the block and cartridge are removed, unscrew the wick cartridge from the inlet block assembly.
5. Unscrew the growth tube cartridge (short section) from the conditioner wick cartridge. If the insulator spacer detaches, reinstall it on the conditioner wick cartridge (longer section). Refer to Figure 9-9 showing disassembled parts of the wick assembly.
6. The conditioner cartridge is in two pieces that can be unscrewed to ease installation of the wick.
7. Remove and discard the old wicks from the cartridges. Clean and dry the parts before installing the new wicks. The spare cartridge assembly can be used and prepared ahead of time for a more rapid swap.

8. Place new wicks in the cartridges. Carefully install the wick in each section by gently twisting the wick to ensure the edges are smoothly inserted and the wick does not crimp. Make sure the central flow path is smooth and unobstructed.
9. With the wicks installed in the cartridges, screw the assembly together. Make sure the wicks are seated against the base of each section to ensure the wick material covers the filling holes at the base of each section. Visually inspect the flow path down the assembly before installing the wick cartridge to the mating inlet block.




Figure 9-9
Inserting New Wicks in Wick Cartridges

10. Replace the inlet assembly making sure the assembly is firmly seated against the mating surface.

(continued on next page)

Flow Checks

The “aerosol flow” through GP_WCPC determines the aerosol concentration. Adjustments to the flow constants can be made using the firmware command SFC to match the measured aerosol flow (see Appendix B, “[Firmware Commands](#)”).

The flow schematic below shows the transport and sample flows through the GP-WCPC.




Figure 9-10
General Purpose Water-based Condensation Particle Counter Flow Schematic

Note: Check each flow after every wick change.

The instructions below describe the procedure for checking the aerosol flow and transport flows.

To check the aerosol flow, follow these instructions:

1. With the instrument powered on and the pump turned on, press **SETUP** on the Home screen, then press **INLET MODE**.
2. Check that the inlet flow is 0.6 L/min. If it is not, select 0.6 L/min as the setting.
3. Attach an external flow meter (such as a Gilibrator) to the aerosol inlet.




Figure 9-11
Aerosol Inlet

4. Using the external flow meter, measure the flow. Verify that the flow is 0.6 L/min $\pm 10\%$. Flow readings lower than the specified value may indicate a blocked aerosol flow orifice.
5. The Transport Flow can be checked by changing the inlet flow setting to 1.5 L/min and checking the inlet flow with the external flow meter for a reading of 1.5 L/min $\pm 10\%$. This flow should be checked after the Aerosol Flow has been verified.

Cleaning the Water Bottle

To prevent bacterial growth and possible contamination, clean the water bottle after every use. To clean the water bottle, follow these instructions:

1. Disconnect the water fill tubing from the **WATER FILL/EXHAUST**.
2. Empty the water bottle.
3. Wash the water bottle with a mild detergent.
4. Thoroughly rinse out the water bottle.

Inspecting and Cleaning the Fans

The fans should not require maintenance, but it is beneficial to perform a visual inspection at intervals to check for dust build up. If any of the fans or heat sinks are dusty, blow them clean with compressed air.

Clean/Replace the Orifices

The Model 3787 GP-WCPC has two orifices:

- Aerosol (total flow) orifice (0.6 L/min).
- Transport flow orifice (0.9 L/min).

To clean or replace an orifice, follow these instructions:

1. Turn off the power to the GP-WCPC.
2. Remove the instrument cover.
3. Note the direction of flow (indicated by an arrow on the label).




Figure 9-12
Arrow Showing Direction of Flow on Orifice

4. Grasp the tubing on either side of the orifice and pull firmly to detach the tubing from the orifice.
5. Using a microscope, inspect the orifice. If debris is present, soak the orifice in isopropyl alcohol for 20 minutes.




Figure 9-13
Inspect Orifice

6. Using compressed air at <60 psi, blow out the orifice and then re-inspect under the microscope.

7. If the orifice is clean, replace it in the instrument making sure you match the direction of flow with the original direction of flow.
8. If the orifice is not clean, replace it with a new one.

Note: Replacement orifices are supplied by TSI Inc.

9. Replace the instrument cover.

Inspect Tubing

Liquid flow tubing should be inspected to check for cracks, damage, loose fit, or leaks. Inspect the following water filling lines:

- The lines that flow from the fill connectors (located on the front and back panels) to the fill valve.
- The water line from the fill valve to the GP-WCPC engine.

Replace any damaged tubing with tubing from the supplied maintenance kit.

Note: Liquid flow tubing is replaced as part of the TSI factory annual service.

Status Messages

Status messages display at the top of the Home screen. The messages are as follows.

Table 9-2
Status Messages

Status Message	Explanation
Low Water	Water level is low
Warmup	Instrument is warming up
Laser Fault	Laser malfunction
Inlet Pressure Fault	Inlet pressure is too high/low
Vacuum Fault	Vacuum pressure is too low
Nozzle Fault	Pressure drop across the Nozzle is out of range
Absolute Pressure Fault	Barometric pressure is out of range
Optics Temp Fault	Optics temperature is out of range
Growth Tube Temp Fault	Growth Tube temperature is out of range
Conditioner Temp Fault	Conditioner temperature is out of range
Separator Temp Fault	Separator temperature is out of range
Pulse Height Fault	Low pulse height
Prescan	Pre-scan condition – SMPS mode
Up Scan	Scan in the up direction – SMPS mode
Down Scan	Scan in the down direction – SMPS mode
Scan Pause	Pause in the scanning process – SMPS mode
Ready	Warm-up process has finished, the pump is operating and no fault conditions are detected. The GP-WCPC is ready for use

Note: *The messages are a warning that there may be a problem with the instrument, but only one message can display at a time. Check the Status screen for more details about potential problems.*

Troubleshooting

The **STATUS** screen displays the status of the operating conditions in real-time. The table below provides basic information about some status messages and suggestions for corrective action.

Table 9-3
Troubleshooting

Problem	Cause	Suggestions
Nozzle fault indicated on the Home screen and low Nozzle Pressure (<50%) indicated on the Status screen.	<p>Low sample flow.</p> <p>Likely causes:</p> <p>There is an obstruction in the Sample Flow Orifice.</p> <p>The Sample Flow Filter is wet. This may result after a flooding incident, or result from poor performance of the Water Separator.</p> <p>Water present in the pressure transducer sample lines.</p>	<p>Verify 0.6 L/min inlet flow as described in the Flow Checks section of this chapter. If flow is OK, check for the presence of water in the Pressure Transducer sample lines.</p> <p>The Sample Orifice is likely clogged or dirty and needs cleaning or replacement.</p> <p>Replace the Sample filter if it appears wet. A wet filter may indicate flooding or poor performance of the Water Separator. The problem may be seen as presence of water in the tubing immediately upstream of the filter. Replace the Sample Filter. Also mark flow direction with a marker and remove the filter Screen found downstream of the Sample Filter. Use compressed air to blow back through the Screen to remove trapped material. Replace the Screen in its original orientation as indicated by the mark.</p> <p>Poor performance of the Water Separator may result if the instrument is operated outside its temperature and humidity specification range.</p>
Nozzle fault indicated on the Home screen and high Nozzle Pressure (>300%) indicated on the Status screen.	<p>The pressure over the nozzle is high indicating that the nozzle may be plugged or the path ahead of the nozzle is obstructed. Obstruction may be due to an improperly installed, twisted wick or the presence of excess water.</p>	<p>Verify 0.6 L/min inlet flow as described in the Flow Checks section of this chapter.</p> <p>Disconnect the water bottle and remove the inlet block and wick assembly as described earlier in this chapter. If the Nozzle Pressure % remains high, the nozzle is plugged. The nozzle is not user serviceable, contact TSI.</p> <p>If the Nozzle Pressure % drops to near 100% after wick assembly removal, a restriction in the wick cartridge is indicated. Unscrew the wick cartridge from the inlet block and the growth tube from the conditioner. Look through the wick tube to verify an open path. If there is no clear path, (e.g. the wick is twisted causing a blockage), refer to the manual section on replacing the wick.</p> <p>If there appears to be excessive water dripping from the instrument after inlet removal, flooding may have occurred. Disconnect the water fill bottle at the quick disconnect and allow the instrument to run for a few hours without the wick cartridge installed. This will dry the instrument.</p>
Home screen displays Inlet Pressure Fault. Status screen displays a low inlet pressure reading (in red).	<p>There is an obstruction in the aerosol line or GP-WCPC inlet.</p>	<p>Check and clear any kinks or obstructions in the tubing upstream of the Aerosol Inlet. Check and ensure that upstream pressure restrictions are within the GP-WCPC's operating limits.</p>

Problem	Cause	Suggestions
Separator/Optics/Growth Tube/Conditioner temperatures out of range. Error messages are displayed on the home screen and the Status screen shows readings in red.	Either the instrument was flooded or environmental temperatures maybe too high. <i>Note: If the instrument was flooded, you will also see water in the tubing and high nozzle pressure readings.</i>	Disconnect the water bottle from the WATER INLET/DRAIN . Run the instrument for 6 to 8 hours to dry it out. When the flow returns to normal, the instrument is dry. Reconnect the water bottle. If concentrations do not return to normal, contact TSI Inc. for service.
Status screen indicates Water Reservoir Not Filled.	There is no water in the reservoir. The water bottle is not connected, is empty, or has been placed below the level of the top of the instrument.	Check that the water bottle is filled and connected correctly. Make sure that the bottle is placed at a higher level than the instrument to provide for the gravity flow fill mechanism. If the problem persists, contact TSI Inc. for service.
Status screen Pulse Height indicator is too low (in the red area).	The particle pulse height is low. This can be caused by particles with a size near the detection limit of the GP-WCPC (5 nm), low water or dry wick, optical alignment, or dirty or flooded optics.	This indicator provides an indication of the nominal health of the instrument and the growth of particles. This flag may be present for low concentrations or concentrations of particles near the detection limit of the instrument. If the flag persists while sampling typical room aerosol concentrations, make sure water is not low and that the wicks have been replaced in the normal maintenance cycle (<700 hours). Also check for flooding indicated by water dripping from the inlet or water is present just ahead of the Sample Filter. To dry flooded optics: <ul style="list-style-type: none"> • Disconnect the water bottle from the WATER INLET. • Run the instrument for 6 to 8 hours to dry it out. • When the flow returns to normal, the instrument is dry. Reconnect the water bottle. If pulse heights do not return to normal, return the instrument to TSI Inc. for repair.
The real-time clock does not maintain time when the instrument is turned off.	The clock battery is dead.	Replace the clock battery located on the main electronics board with a BR1225 Panasonic or equivalent.

Technical Contacts

- If you have any difficulty installing the GP-WCPC, or if you have technical or application questions about this instrument, contact an applications engineer at TSI Incorporated, (651) 490-2811 or contact technical.service@tsi.com.
- If the GP-WCPC fails, or if you are returning it for service, visit our website at <http://rma.tsi.com> or contact TSI at:

TSI Incorporated
500 Cardigan Road
Shoreview, MN 55126 USA
Phone: 1-800-874-2811 (USA) or 001 (651) 490-2811
E-mail: technical.service@tsi.com
Website: <http://service.tsi.com>

Returning the Model 3787 for Service

Before returning the Model 3787 GP-WCPC to TSI for service, visit our website at <http://rma.tsi.com> or call TSI at 1-800-874-2811 (USA) or 001 (651) 490-2811 for specific return instructions. When you call, have the following information ready for the Customer Service representative:

- Instrument model number
- Instrument serial number
- A purchase order number (unless under warranty)
- A billing address
- A shipping address

TSI recommends that you keep the original packaging of the GP-WCPC for use whenever the instrument is shipped, including when it is returned to TSI for service. Always seal off the sampling inlet to prevent debris from entering the instrument and dry the GP-WCPC before shipping. If you no longer have the original packing material, first protect the GP-WCPC by placing it inside a plastic bag. Then package the unit with at least 5" (13 cm) of shock absorbing/packaging material around all six sides of the GP-WCPC.

See [Moving and Shipping](#) in Chapter 3 for detailed instructions.

(This page intentionally left blank)

APPENDIX A

Specifications

Table A-1 contains the operating specifications for the Model 3787 General Purpose Water-based Condensation Particle Counter (GP-WCPC). Specifications reflect typical performance and are subject to change without notice.

Table A-1

Model 3787 General Purpose Water-based Condensation Particle Counter Specifications

Particle Size Range	
Min detectable particle (D_{50})	5 nm, verified with DMA-classified sucrose
Max detectable particle	>3 μm
Particle Concentration Range	
Single Particle Counting	0 to 2.5×10^5 particles/cm ³ , with continuous live-time coincidence correction
Particle Concentration Accuracy	
Accuracy	$\pm 10\%$ @ < 2.5×10^5 particles/cm ³
Response Time (to step change in concentration)	
High flow mode (1.5 L/min)	~700 ms to 95% in response to concentration step change <300 ms Rise Time (10 to 90%) ~130 ms Time Constant (τ)
Low flow mode (0.6 L/min)	~ 1000 ms to 95% in response to concentration step change
Flow	
High-flow inlet	1.5 ± 0.15 L/min
Aerosol flow rate	0.6 ± 0.06 L/min
False Background Counts	
False background counts	<0.01 particles/cm ³ , 12-hour average Dewpoint <30°C (i.e. <35°C @ 75% RH)
Aerosol Medium	
Aerosol medium	Air only
Environmental Operating Conditions	
Ambient temp range	10 to 35°C (50 to 95°F) Dewpoint <30°C (i.e. <35°C @ 75% RH)
Ambient humidity range	0 to 90% RH, non-condensing
Inlet Pressure Operation	
Inlet pressure operation (absolute)	75 to 110 kPa (0.75 to 1.1 atm)
Inlet pressure gauge	0 to -5 kPa (-20 inch H ₂ O)

Water System	
Condensing liquid	Distilled (<6 ppm) or HPLC grade water; tap water must not be used)
Water system	External 1000 ml bottle used in recycle mode for up to 30 days of continuous operation
Water consumption	<33 ml/day
Vacuum	
Vacuum	Internal vacuum pump
Communications	
Protocol	ASCII command set
Interfaces	
RS-232	9-pin, D-Sub connector
USB	Type B connector, USB 2.0 compatible at 12 MB
Ethernet	8-wire RJ-45 jack, 10/100 BASE-T, TCP/IP
Data Logging	
Data logging	USB Flash drive
Averaging interval	Data averaging interval of 1 to 3600s 1,2,4,5,6,10,12,15,20,30 or 60s software provides more averaging options.
Outputs	
Digital display	6 inch QVGA color touch screen w graphical interface. Graph of conc vs. time, concentration, time and total counts, and status
Analog output	BNC connector, 0 to 10V proportional to concentration or Log ₁₀ Conc
Software	
Software	TSI Aerosol Instrument Manager [®] software included
Calibration	
Calibration	Recommended annually
Power	
Requirements	100 to 240 VAC, 50/60 HZ, 200 W max
Physical Features	
Front panel	Display, sample inlet, LED particle indicator
Back panel	Power connector, USB, Ethernet, RS-232, BNC output, fan, water fill connector, pump exhaust port, fill bottle and bracket
H x W x D	30.5 x 16 x 36 cm (12 x 6.25 x 14.25 in.) not including water supply bracket
Weight	8.2 kg (18 lbs)

APPENDIX B

Firmware Commands

The firmware commands are divided into the following categories:

Commands	Description
READ	Used to read parameters from the instrument (such as flow rate, pressure, temperature, etc.). READ commands can be identified by a leading "R".
SET	Set an internal parameter to the value(s) supplied with the command (supplied parameters are always delimited by a comma). SET commands can be identified by a leading "S". The instrument will reply to all SET commands with the string "OK"<CR>.

Note: When the instrument does not understand a command, it replies with the string "ERROR".

Table B-1 is a quick reference of all the firmware commands. More detailed information about each command can be found on the following pages.

Note: The commands are not case sensitive.

Table B-1
Model 3787 Firmware Commands

Command	Explanation
Read Commands	
RAI	Read Analog Input
RALL	Read Operating Condition
RCT	Read Current Time
RD	Read Displayed Concentration
RIE	Read Instrument Errors
RIF	Read Inlet Flow Rate
RIS	Read Instrument Status
RL	Read Laser Current
RLL	Reads Liquid Level
RPA	Read Absolute Pressure
RPN	Read Nozzle Pressure
RPV	Read Vacuum Pressure
RRD	Read Data Record
RRS	Read Status Record
RSF	Read Sample Flow
RTA	Read Cabinet Temperature
RTC	Read Conditioner Temperature
RTG	Read Growth Tube Temperature

Command	Explanation
Read Commands	
RTO	Read Optics Temperature
RV	Read Version
Set Commands	
SM	Set Mode x =mode t =sample time in tenth of second
SFC	Set Flow Rate Calibration Constant
SP	Set Pump On/Off
SR	Set Real Time Clock
SSTART	Start a New Sample
ST	Set Transport Flow On/Off
SMPS™ Spectrometer Scanning Commands	
ZB	Begin Scan
ZE	End Scan
ZT	Set Scan Time
ZU	Scan Up
ZV	Set Scan Voltage

READ Commands

Read Commands are used to display specific data values. The values, associated parameters, responses returned by the Model 3787, and examples are given on the following pages.

RAI – Read Analog Input Voltage

RAI reads the analog input voltage in V.

RAI		
Command	RAI	
Response	X	X = analog input ZZAs (a floating point number from 0.00 to 10.00)
Example		
Command	RAI	Read Analog Input Voltage
Response	5.22	Voltage = 5.22 V

RALL – Read Operating Condition

RALL reads the Model 3787 GP-WCPC's operating condition, calibration parameters, and diagnostic parameters.

RCT – Read Current Time

RCT reads the current time.

RCT		
Command	RCT	
Response	yyyy/mm/dd,hh:mm:ss	yyyy = year mm = month (1 – 12) dd = day (1 – 31) hh:mm:ss = time (hours, minutes, seconds)
Example		
Command	RCT	Read Current Time
Response	2012/9/18,20:22:19	Year = 2012 Month = September Day = 18 Hour = 8 pm Minutes = 22 Seconds = 19

RD – Read Displayed Concentration

RD is a legacy command that reads the displayed concentration in particles/cm³.

RD		
Command	RD	
Response	x	
Example		
Command	RD	Read Displayed Concentration
Response	3.16e ⁴	

RIE – Read Instrument Errors

RIE reads the instrument errors (displayed as a 16-bit integer in hexadecimal format). The number may be a combination of the values of more than one flag.

RIE		
Command	RIE	
Response	Bit 0 x XXXX	Bit = Hexadecimal character A-F. When the bit is set, the parameter is in error. XXXX = 4-digit number 0x0001 = Conditioner Temperature 0x0002 = Growth Tube Temperature 0x0004 = Optics Temperature 0x0008 = Vacuum Level 0x0020 = Laser Status 0x0040 = Water Level 0x0080 = Concentration Over-range 0x0100 = Pulse Height Fault 0x0200 = Absolute Pressure 0x0400 = Nozzle Pressure 0x0800 = Water Separator Temperature 0x1000 = Warmup 0x2000 = Reserved 0x4000 = Service Reminder 0x8000 = Reserved
Example		
Command	RIE	Read Instrument Errors
Response	C00	Water Separator Temperature and Nozzle Pressure faults (Nozzle Pressure = hexadecimal 4. Water Separator = hexadecimal 8. Added together they make hexadecimal C.)

Note: Hexadecimal is a numerical system using a base of 16. The symbols 0 to 9 represent the values zero to nine, and the letters A to F represent the values ten to sixteen. It is a useful “shorthand” for computer engineering because each hexadecimal digit represents four binary digits.

RIF – Read Aerosol Flow Rate

RIF reads the inlet flow rate in liters per minute (L/min).

RIF		
Command	RIF	
Response	X	X = Floating point number either 0.6, or 1.5
Example		
Command	RIF	Read Inlet Flow Rate
Response	1.5	1.5 L/min

RIS – Read Instrument Status

RIS reads the instrument status (displayed as 13 comma-separated fields).

RIS		
Command	RIS	
Response	X	X = 1-13 1 = Concentration (#/cm ³) 2 = Livetime (%) 3 = Photo value (mv) 4 = Inlet Pressure (mBar) 5 = Nozzle Pressure (%) 6 = Inlet Flow Mode (0.6, 1.5 L/min) 7 = Analog Input Voltage (mV) 8 = Pulse Height (mV) 9 = Optics Temp (°C) 10 = Growth Tube Temp (°C) 11 = Conditioner Temp (°C) 12 = Water Separator Temp (°C) 13 = Water Reservoir (Filled/Not Filled, 0/1)
Example		
Command	RIS	Read Instrument Errors
Response	0.00, 100, 92 1002, 100, 1.5, 0.00, 0, 60.0, 60.0, 20.0, 20.0, 0	Particle Concentration Livetime Photo value Inlet Pressure Nozzle Pressure Inlet Flow Mode Analog Input Voltage Pulse Height Optics Temp Growth Tube Temp Conditioner Temp Water Separator Temp Water Reservoir (Filled)

RL – Read Laser Current

RL reads laser current in mA.

RL		
Command	RL	
Response	X	X = 0 to 50
Example		
Command	RL	Read Inlet Flow Rate
Response	30	30 mA

RLL – Read Liquid Level

RLL reads the liquid level.

RLL		
Command	RLL	
Response	FULL/NOTF ULL X	X = ADC reading from 0 to 4095
Example		
Command	RLL	Read Liquid Level
Response	FULL,2471	FULL – water level ADC - 2471

RPA – Read Absolute Pressure Transducer

RPA reads the absolute pressure transducer in mbars.

RPA		
Command	RPA	
Response	X	X = A floating point number from 150 to 1150
Example		
Command	RPA	Read Absolute Pressure
Response	1001	

RPN – Read Nozzle Pressure Transducer

RPN reads the nozzle pressure transducer in percent.

RPN		
Command	RPN	
Response	X	X = A floating point number from 0 to 2050
Example		
Command	RPN	Read Nozzle Pressure
Response	100	

RPV – Read Nozzle Pressure Transducer

RPV reads the vacuum pressure transducer in mbars.

RPV		
Command	RPV	
Response	X	X = A floating point number from 0 to 1150
Example		
Command	RPV	Read Vacuum Pressure
Response	408	

RRD – Read Data Record

RRD returns the current data values in the “D” record format. Data records are collected according to the time period you have specified for the data collection interval.

RRD		
Command	RRD	
Response	D record (see below)	
	D	Record identifier
	Date	Date in yyyy/mm/dd format
	Time	Time in hh:mm:ss format
	Flags	Status Flags (see information in RIE command description).
	Conc	Aggregated concentration calculated by dividing the accumulated aggregate counts by the live-time of the sample flow rate (nominally 10 cm ³ /sec). The aggregated counts and live-times are accumulated each 1/10 th second interval. The overflow flag is set when the concentration value exceeds the maximum specified concentration.
	AT	Elapsed sample time 0.1 sec resolution (0.1 to 3600).
	LT	Live time 0.001 sec resolution (0.001 to 3600).
	CNT	Accumulated particle counts.
	Photo	Average photo-detector value in mV.
	PH	Average pulse height in mV.
	PSTD	Pulse height standard deviation.

D records contain the following information:

Example D Record:

D,2012/11/2,08:01:21,0,1.04e4,6.0,4.4,769424,140,,0,0

Record Type	Date	Time	Flags	Conc	AT	LT	CNT	Photo	PH	PSTD
D	2012/11/2	08:01:21	0	1.04e4	6.0	4.4	769424	140	0	0

RRS – Read Status Record

RRS returns the current raw analog values in “S” record format for diagnostic use.

RRS		
Command	RRS	
Response	S record (see below)	
	S	Record identifier
	AP	Absolute pressure in mbars
	ST	Saturator Temperature in degrees Celsius
	GT	Growth Tube temperature in degrees Celsius
	OT	Optics temperature in degrees Celsius
	WT	Water Separator temperature in degrees Celsius
	FL	Sample flow rate in cm ³ /min

Example S Record:
S,1003,20.0,60.0,60.0,7.0,124.0

Record Type	AP	ST	GT	OT	WT	FL
S	1003	20.0	60.0	60.0	7.0	124.0

RSF – Read Sample Flow Rate

RSF reads the aerosol sample flow rate in cm³/min.

RSF		
Command	RSF	
Response	X	X = A floating point number from 0.0 to 999.9
Example		
Command	RSF	Read Sample Flow
Response	300	300 cm ³ /min

RTA – Read Cabinet Temperature

RTA reads the cabinet (ambient) temperature in degrees Celsius.

RTA		
Command	RTA	
Response	X	X = A floating point number from 0.0 to 60.0
Example		
Command	RTA	Read Cabinet Temperature
Response	23.8	23.8°C

RTC – Read Condenser Temperature

RTC reads the conditioner temperature in degrees Celsius.

RTC		
Command	RTC	
Response	X	X = Floating point number from 0.0 to 50.9
Example		
Command	RTC	Read Saturator Temperature
Response	20.0	20.0°C

RTG – Read Growth Tube Temperature

RTG reads the Growth Tube temperature in degrees Celsius.

RTG		
Command	RTG	
Response	X	X = Floating point number from 0.0 to 80.0
Example		
Command	RTG	Read Growth Tube Temperature
Response	60.0	60.0°C

RTO – Read Optics Temperature

RTO reads the optics temperature in degrees Celsius.

RTO		
Command	RTO	
Response	X	X = Floating point number from 0.0 to 80.0
Example		
Command	RTO	Read Saturator Temperature
Response	60.0	60.0°C

RV – Read Firmware Version Number

RV returns the instrument model number, firmware version number, and serial number.

RV		
Command	RV	
Response	Model 3787 Ver v.vv S/N nnnn	v.vv = ranges from 0.01 to 9.99 (3 digits) nnnn ranges from 100 to 99999999)
Example		
Command	RV	Read Version Number
Response	Model 3787 Ver 1.05 S/N 1004	Model 3787 = Model # Ver 1.05 = Version # S/N 1004 = Serial Number

SET Commands

Set commands are used to set instrument parameters and data collection modes. You will use the Set Mode (SM) command to control data collection.

SM – Set Mode

SM is used to set the data collection mode and the sample interval. At the end of each sample interval, the data is reported and, if in a continuous mode, the data is cleared internally and the next sample is started. The four available modes are shown in the list below.

Mode	Description
0	Idle. No data collection.
1	Continuously collects data and reports data (“D” record) at end of every sample interval.
2	Continuously collects data and reports data (“S” record) at end of every sample interval.
3	Continuously collects data and reports data (“D” record) at end of every sample interval. Concatenates “S” record to the “D” record.

SM		
Command	SM,n,tttt	n = mode (0,1,2,3) tttt – sample interval
Response	OK	Response issued after parameters changed.
Example		
Command	SM,1,60	Continuous data collection (response mode 1) at 6 second sample intervals.
Response	OK	
Command	SM	Parameters not changed.
Response	1,60	Continuous data collection (response mode 1) at 6 second sample intervals.

Note: To stop data collection, enter SM,0 in the Firmware Command field.

SFC – Set Flow Rate Calibration Constant

SFC is used to set the flow rate calibration constant or to return the value of the current setting if no parameter is supplied.

SFC		
Command	SFC,cccc	cccc = 1000 to 15000
Response	OK	Response issued after parameters changed.
Example		
Command	SFC,6050	Changes the flow rate constant to 605.0 cm ³ /min.
Response	OK	
Command	SFC	
Response	6050	Parameter not changed. Current setting displayed on record.

SP – Set Pump Vacuum

SP is used to turn the pump vacuum on or off. The default setting at power-up is On.

SP		
Command	SP,x	x = 0 turns vacuum off x = 1 turns vacuum on
Response	OK	Response issued after parameters changed.
Example		
Command	SP,0	Turns the vacuum off.
Response	OK	
Command	SP	
Response		Parameter not changed – current setting displayed on record.

SR – Set Real-time Clock

SR is used to set the clock. When the Model 3787 is powered off, the setting is saved (it does not revert to the default).

SR		
Command	SR,yy,mm,dd,hh, mm,ss	yy = year (2 or 4 digits) mm = month (1-12) dd = day (1-31) hh = hour (0-23) mm = minutes (0-59) ss = seconds (0-59) Note: mm and ss are 0 if not included.
Response	OK	Response issued after parameters changed.
Example		
Command	SR,12,5,6,15,34	Clock is set to May 6, 2012 3:34 pm
Response	OK	
Command	SR	
Response	10,5,6,15,34	Parameter not changed – current setting displayed on record.

SSTART – Starts a New Sample

SSTART is used to start a new sample routine. U records are displayed when the SSTART,3 command is entered. The records are returned once per second.

SSTART		
Command	SSTART,x	X = 0,1,2,3 0 = Stop 1 = Start data type 1 (not used) 2 = Start data type 2 (not used) 3 = Start s new sample
Response	OK	Response issued after parameters changed.
Example		
Command	SSTART,0	Stops sample.
Response	OK	
Command	SSTART,3	Starts new sample.
Response	OK	
Command	SSTART	
Response	3	Parameter not changed – current setting displayed on record.
	U	Record type.
	X	Elapsed time in seconds (integer).
	C	Concentration in 1/10 th second intervals (float).
	R	Raw counts in 1/10 th second intervals (integer).
	X	Flow in cm ³ /min
	T	Live time in 1/10 th seconds (float).
	D	DTC value (float).
	P	Absolute pressure in millibars (integer).
	AN	Analog input.
	HM	Pulse height mean in millivolts (integer).
	HS	Pulse standard deviation in millivolts (integer).
	IS	Instrument Status (use RIE command to see a list of statuses).

Example U record:

UX,C,C,C,C,C,C,C,C,C,C,C,C,R,R,R,R,R,R,R,R,R,R,T,T,T,T,T,T,T,T,T,D,P,AN,HM,HS, IS

ST – Set Transport Flow

ST is used to turn the transport flow on or off. The default setting at power-up is On.

ST		
Command	ST,x	x = 0 turns flow off x = 1 turns flow on
Response	OK	Response issued after parameters changed.
Example		
Command	ST,0	Turns the flow off.
Response	OK	
Command	ST	
Response		Parameter not changed – current setting displayed on record.

SMPS™ Spectrometer Scanning Commands

ZB – Begins SMPS™ Spectrometer Scan

ZB begins the SMPS™ spectrometer scan based on the ZT, ZV, and ZU parameters.

ZB		
Command	ZB	Begins scan
Response	OK	Response issued after parameters changed.

ZE – Ends SMPS™ Spectrometer Scan

ZE ends the SMPS™ spectrometer scan.

ZE		
Command	ZE	Begins scan
Response	OK	Response issued after parameters changed.

ZT – Sets SMPS™ Spectrometer Scan Time

ZT sets the duration of the SMPS™ spectrometer scan in increments of 1/10th second.

Note: Do **not** use a comma between the command and the first parameter.

ZT		
Command	ZTx,y,z	X = delay, 0 to 255 (0 to 25.5 seconds) y = up, 10 to 6000 (1 to 600 seconds) z = down, 10 to 6000 (1 to 600 seconds)
Response	OK	Response issued after parameters changed.
Example		
Command	ZT0,600,100	No delay, scan up time is 60 seconds, scan down time is 10 seconds.
Response	OK	Response issued after parameters changed.
Command	ZT	Returns current setting.

ZU – Sets SMPS™ Spectrometer Scan Direction Up

ZU sets the scan direction up.

ZU		
Command	ZU	Scan direction up.
Response	OK	Response issued after parameters changed.

ZV – Sets SMPS™ Spectrometer Scan Voltages

ZV sets the SMPS™ spectrometer scan voltages in Volts.

Note: Do **not** use a comma between the command and the first parameter.

ZV		
Command	ZVx,y	x = start, 10 to 1000 Volts y = end, 10 to 10000 Volts
Response	OK	Response issued after parameters changed.
Example		
Command	ZV10,1000	Starting voltage 10V, ending voltage 1000V.
Response	OK	Response issued after parameters changed.
Command	ZV	Returns current setting.

DATA Reporting Records

The Model 3787 GP-WCPC displays data in real time on the front panel display. You can also collect data records over time. Data records include the following:

D Records	Used for data collection
S Records	Used for data collection
U Records	Used by Aerosol Instrument Manager® software

D Record

D records contain the following information:

D	Record identifier
Date	Date in yyyy/mm/dd format
Time	Time in hh:mm:ss format
Flags	Status Flags (see information in RIE command description).
Conc	Aggregated concentration calculated by dividing the accumulated aggregate counts by the live-time of the sample flow rate (2 cm ³ /sec). The aggregated counts and live-times are accumulated each 1/10 th second interval. The overflow flag is set when the concentration value exceeds the maximum specified concentration.
AT	Elapsed sample time 0.1 sec resolution (0.1 to 3600).
LT	Live time 0.001 sec resolution (0.001 to 3600).
CNT	Accumulated particle counts.
Photo	Average photo-detector value in mV.
Res	Blank value
PH	Average pulse height in mV.
PSTD	Pulse height standard deviation.

Example D Record:

D,2012/11/2,08:01:21,0,1.04e4,6.0,4.4.769424,140,,0,0

Record Type	Date	Time	Flags	Conc	AT	LT	CNT	Photo	Res	PH	PSTD
D	2012/11/2	08:01:21	0	1.04e4	6.0	140	0	0		0	0

S Record (Status)

S records are displayed on the Text tab when you enter the command **RRS** in the Firmware Command field. They display status information.

U Record

U records are displayed when the **SSTART,3** command is entered. The records are returned once per second. They contain the following information:

U	Record type.
X	Elapsed time in seconds (integer).
C	Concentration in 1/10 th second intervals (float).
R	Raw counts in 1/10 th second intervals (integer).
X	Flow in cm ³ /min.
T	Live time in 1/10 th seconds (float).
D	DTC value (float).
P	Absolute pressure in millibars (integer).
AN	Analog input.
HM	Pulse height mean in millivolts (integer).
HS	Pulse standard deviation in millivolts (integer).
IS	Instrument Status (use RIE command to see a list of statuses)

Example U record:

UX,C,C,C,C,C,C,C,C,C,R,R,R,R,R,R,R,R,R,R,R,R,T,T,T,T,T,T,T,T,T,T,D,P,
AN,HM,HS, IS

(This page intentionally left blank)

APPENDIX C

References

The following sources have been used in the text of this manual.

-
- Agarwal, J.K. and G.J. Sem [1980]
“Continuous Flow Single-Particle-Counting Condensation Nuclei Counter”
J. Aerosol Sci., Vol. **11**, No. 4, pp. 343–357
- Aitken, J. [1888]
“On the Number of Dust Particles in the Atmosphere”
Proc. Royal Soc. Edinburgh, **35**
- Aitken, J. [1890-1891]
“On a Simple Pocket Dust Counter”
Proc. Royal Soc. Edinburgh, Vol. XVIII
- Allen, J; Cubison, M.; Hering, S.; Ogren, J.; Jimenez, J-L; Carlo, P.; Goldstein, A.; Millet, D. [2005]
“Observation of Biogenic Nucleation Events at Low Tide in Nova Scotia, Canada”.
Presentation, 24th Annual AAAR Conference, Austin TX, October 17-21, 2005
- Arhami, Mohammad; Polidori, Andrea; Delfino, Ralph J.; Siousta, Constantinos, [2006]
“Indoor/Outdoor Relationships, Trends and Carbonaceous Content of Fine Particulate Matter during the CHAPS study”
2006 International Aerosol Conference, St. Paul, MN, September 10–15, 2006
- Attoui, MB; de la Mora, J. Fernandez [2005]
“On the Detection Limit of Hydrophilic Particles by a Water CPC,”
Presentation,
2005 European Aerosol Conference, Ghent, Belgium, August 28–September 2, 2005
-
- Berndt, Torsten; Böge; Stratmann, Frank, [2006]
“Formation of atmospheric H₂SO₄/H₂O particles in the absence of organics”
2006 International Aerosol Conference, St. Paul, MN, September 10–15, 2006
- Birmili, Wolfran; Mordas, Genrik; Petäjä, Tuuka.; Aalto, Pasi P.; Riipinen, Ilona; Grönholm, Tiia; Hämeri, Kaarle; Kulmala, Markku [2006]
“Activation properties of atmospheric nano-particles in the size range of 3 to 10 nanometers: contrasts between urban and rural observations”
2006 International Aerosol Conference, St. Paul, MN, September 10–15, 2006

Bischof, O.F.; Zerrath, A.F. [2005]
“Measurements of Urban Aerosol in a Light Industrial Area – Physical Properties, Including Particle Size, Number, and Diameter Concentrations”.
Poster
24th Annual American Association for Aerosol Research Conference,
Austin, Texas, October 17–21, 2005

Biswas, Subhasis, Fine, Philip M., Geller, Michael D., Hering, Susanne V.,
Sioutas, Constantinos, [2005]
“Performance Evaluation of a Recently Developed Water-Based
Condensation Particle Counter.”
Aerosol Science & Technology, **39(5)**, pp. 419-427

Bradbury, N.E. and H.J. Meuron [1938]
“The Diurnal Variation of Atmospheric Condensation Nuclei”
Terr. Magn., **43**, pp. 231–240

Bricard, J., P. Delattre, G. Madelaine, and M. Pourprix [1976]
“Detection of Ultrafine Particles by Means of a Continuous Flux
Condensation Nucleus Counter”
in *Fine Particles*, B.Y.H. Liu, ed., Academic Press, New York, pp. 565-580

Caldow, R. and P.B. Keady [1990]
“Performance of an Ultrafine Condensation Particle Counter.”
*Aerosols Science, Industry, Health and Environment - Proceedings of the
3rd International Aerosol Conference, Kyoto Japan*, (S. Masuda and
K. Takahashi, ed.) **1**, 503-506

Eiguren-Fernandez, A; Zhu, Y.; Miguel, A.; Hinds, W.; Hering, S.; Nazaroff,
W. [2005]
“In-Cabin and Outdoor Nanoparticles, and Ultrafine Particles II: Collocated
Number Concentration Measurements on Los Angeles Roadways”.
Presentation, 24th Annual AAAR Conference, Austin TX,
October 17-21, 2005

Erickson, Kathy; Liu, Wei; Osmondson, Brian; Oberreit, Derek R.;
Schiesher, Nathaniel; Quant, Frederick [2006]
“Performance Characterization of a Compact Water-Based Condensation
Particle Counter (TSI Model 3781)”
International Aerosol Conference 2006, St. Paul, MN, USA,
September 10–15, 2006

Filimundi, E.; Bischof, O.F.; Bennett, I.P. [2005]
“Measurement of nucleation mode particles using an ultrafine water-based
condensation particle counter”.
Presentation, Le 21ème Congrès Français sur les Aérosols (CFA 2005).
ASFERA, Paris, France, December 14–15, 2005

Hering, S., Keady, P.B.; Stolzenburg, M.R.; Fernandez, A.E.; Miguel, A. H.; Quant, F.R.; Oberreit, D.R. [2005]

“Response of Water-Based Condensation Particle Counters to Ambient and Vehicular Particulate Matter”

Presentation, 2005 European Aerosol Conference, Ghent, Belgium, August 28–September 2, 2005

Hering, Susanne V.; Lewis, Gregory S.; Quant, Fred R.; Oberreit, Derek R. [2006]

“A Micro-Environmental, Water-Based, Condensation Particle Counter”
Poster

2006 International Aerosol Conference, St. Paul, MN,
September 10–15, 2006

Hering, Susanne V., Olga Hogrefe, G. Garland Lala and Kenneth L Demerjian [2004]

“Field Evaluation of a Laminar-Flow, Water-Based Condensation Particle Counter,” Poster

American Association for Aerosol Research 2004 Annual Conference,
Atlanta, GA, October 4–8, 2004

Hering, Susanne V., Stolzenburg, Mark R. [2005]

“A Method for Particle Size Amplification by Water Condensation in a Laminar, Thermally-Diffusive Flow.”

Aerosol Science & Technology, **39**(5):428-436

Hering, Susanne V.; Stolzenburg, Mark R.; Quant, Frederick R.; Keady, Patricia B.; Oberreit, Derek [2005]

“A Fast-Response, Nanaoparticle Water-Based Condensation Counter.”

Presentation, the Particulate Matter Supersite program and Related Studies, An International Specialty Conference sponsored by the American Association for Aerosol Research, Atlanta, GA,
February 7–11, 2005

Hering, Susanne V; Stolzenburg, Mark R. [2004]

“Continuous, laminar flow water-based particle condensation device and method”

US Patent # 6,712,881, March 30, 2004

Hering, Susanne V., Stolzenburg, Mark R., Quant, Frederick R., Oberreit, Derek, and Keady, Patricia B. [2005]

“A Laminar-Flow, Water-Based Condensation Particle Counter (WCPC).”

Aerosol Science & Technology, **39**(7), pp. 659-672

Hermann, M., Wehner, B., Bischof, O., Han, H.-S., Krinke, T., Liu, W., Zerrath, A., and Wiedensohler, A. [2007]

“Particle Counting Efficiencies of New TSI Condensation Particle Counters.”

Journal of Aerosol Science, **38** pp. 674-682

Hering, S., M.R. Stolzenburg, F.R. Quant, D.R. Oberreit and P.B. Keady [2005]

“A Nano-Particle, Water-Based Condensation Particle Counter”,
Presentation,
24th Annual AAAR Conference, Austin TX, October 17-21, 2005

Hering, Susanne V.; Stolzenurg, Mark R.; Quant, Frederick R.; Oberreit, Derek [2004]

“A Laminar-Flow, Water-Based Condensation Particle Counter,”
Presentation
American Association for Aerosol Research 2004 Annual Conference,
Atlanta, GA, October 4–8, 2004

Hering, Susanne V., Stolzenburg, Mark R.; Quant, Frederick R.; Oberreit, Derek [2003]

“A Continuous, Laminar Flow, Water-based Condensation Particle Counter,” Poster
American Association for Aerosol Research 2003 Annual Conference,
Anaheim, CA, October 2003

Hering, S. V.; Quant, F. R. [2005]

“Two New Water-Based Condensation Particle Counters.”
Presentation, *American Geophysical Union, Fall Meeting*, San Francisco,
CA, December 5–9, 2005

Hermann, M., Wehner, B., Bischof, O., Han, H.-S., Krinke, T., Liu, W., Zerrath, A., and Wiedensohler, A. [2007]

“Particle Counting Efficiencies of New TSI Condensation Particle Counters”
Journal of Aerosol Science, **38**:674-682

Hirschl, Rhonda S.; Lee, Shan-Hu [2006]

“Aerosol Nucleation Rates of Sulfuric Acid and Water Measured Under Atmospheric Conditions”
2006 International Aerosol Conference, St. Paul, MN,
September 10–15, 2006

Hogan, A.W. [1979]

“Aerosol Detection by Condensation Nucleus Counting Techniques”
in *Aerosol Measurement*, D.A. Lundgren, ed., Univ. Presses of Florida,
Gainesville, Florida, pp. 497–514

Iida, Kenjiro, Stolzenburg, Mark R., McMurry, Peter H., Smith, James N., Quant, Frederick R., Oberreit, Derek R., Keady, Patricia B., Eiguren-Fernandez, Arantza, Lewis, Gregory S., Kreisberg, Nathan M., and Hering, Susanne V. [2008]

“An Ultrafine, Water-Based Condensation Particle Counter and its Evaluation under Field Conditions.”
Aerosol Science and Technology, **42**, pp. 862-871

Iida, Kenjiro; Stolzenburg, Mark; McMurry, Peter H.; Dunn, Matthew; Smith, James; Eisele, Fred; Keady, Pat [2006]

“Identifying the Contribution of Ion Induced Nucleation from Measurements of Charge Distributions and Aerosol Size Distributions”
2006 International Aerosol Conference, St. Paul, MN,
September 10–15, 2006

Jeong, Cheol-Heon; Evans, Greg J. [2006]

“Intercomparison of the Performance of a Fast Mobility Particle Sizer and an Ultrafine Water-based Condensation Particle Counter for Measuring Particle Number and Size Distributions in the Atmosphere”
2006 International Aerosol Conference, St. Paul, MN,
September 10–15, 2006

Keady, P.B., F.R. Quant and G.J. Sem [1986]

“A Condensation Nucleus Counter for Clean Rooms”
Proc. Institute of Environmental Sci., Annual Technical Mtg, pp. 445-451

Keady, P.B., F.R. Quant and G.J. Sem [1988]

Two New Condensation Particle Counters: Design and Performance
Presented as a poster at the AAAR Annual Meeting, Chapel Hill, NC,
U.S.A.

Keady, P.B., V.L. Denler, G.J. Sem [1988]

A Condensation Nucleus Counter Designed for Ultrafine Particle Detection Above 3-nm Diameter,
Presented at the 12th International Conference on Atmospheric Aerosols and Nucleation, Vienna, Austria.

Keston, J., Reineking, A. and J. Porstendorfer (1991)

“Calibration of a TSI Model 3025 Ultrafine Condensation Particle Counter.”
Aerosol Science and Technology, **15**, 107-111, 1991 (TSI paper A77).

Kousaka, Y. T. Nida, K. Okuyama and H., Tanaka [1982]

“Development of a Mixing-Type Condensation Nucleus Counter”
J. Aerosol Sci., Vol. **13**, No. 3, pp. 231–240

Kulmala, M., Mordas, G., Petjää, T., Grönholm, T., Aalto, P.P., Vehkamäki, H., Hienola, A.I., Herrmann, E., Sipilä, M., Riipinen, I., Manninen, H.E. Hämeri, K., Stratmann, F., Biulder, M., Winkler, P.M., Birmili, W., and Wamer, P.E. [2007]

“The Condensation Particle Counter Battery (CPCB): A New Tool to Investigate the Activation Properties of Nanoparticles.”
Journal of Aerosol Science, **38** pp. 289-304.

Kulmala, Markku; Mordas, Genrik; Petjää, Tuuka,; Grönholm, Tiia; Aalto, Pasi P. Vehkamäki, Hanna; Gaman, Anca; Herrmann, Erik; Sipilä, Mikko; Riipinen, Ilona; Hämeri, Kaarle; Birmili, Wolfran; Wagner, Paul E. [2006]
“Estimation of composition of growing aerosol particles using a condensation particle counter battery”
2006 International Aerosol Conference, St. Paul, MN,
September 10–15, 2006

Liu, B.Y.H. and D.Y.H. Pui [1974]
“A Submicron Aerosol Standard and the Primary Absolute Calibration of the Condensation Nucleus Counter”
J. Coll. Int. Sci., Vol. **47**, pp. 155–171

Liu, W, Kaufman, Stan L.; Sem, Gil J.; Quant, Fred R. [2004]
“Material Effects on Threshold Counting Efficiency of TSI Model 3785 Water-based Condensation Particle Counter,” Poster
American Association for Aerosol Research 2004 Annual Conference, Atlanta, GA, October 2004

Liu, Wei, Kaufman, Stanley L., Osmondson, Brian L., Sem, Gilmore J., Quant, Frederick R., and Oberreit, Derek R. [2006]
“Water-based Condensation Particle Counters for Environmental Monitoring of Ultrafine Particles.”
Journal of Air and Waste Management Association, **56(4)**, pp. 444-455

Miguel, Antonio H.; Eiguren-Fernandez, Arantzazu; Zhu, Yifang, [2005]
“In-Cabin Commuter Exposure to Ultrafine and Nanoparticles in Los Angeles Roads and Freeways: Measurements with a New Water-Based Condensation Particle Counter” Presentation
The Particulate Matter Supersite program and Related Studies, An International Specialty Conference sponsored by the American Association for Aerosol Research, Atlanta, GA, February 2005

Miguel, A.; Zhu, Y; Eiguren-Fernandez A.; Hinds, W.; Hering, S.; Nazaroff, W. [2005]
“In-Cabin and Outdoor Nanoparticles, and Ultrafine Particles I: Size Distribution Measurements on Los Angeles Roadways”. Presentation
24th Annual AAAR Conference, Austin TX, October 17-21, 2005

Miller, S.W. and B.A. Bodhaine [1982]
“Supersaturation and Expansion Ratios in Condensation Nucleus Counters: an Historical Perspective”
J. Aerosol Sci., Vol. **13**, No. 6, pp. 481–490

Mordas, G.; Kulmala, M.; Petäjä, T.; Hämeri, K. [2006]
“Calibration of the Ultra-fine Water-based Condensation Particle Counter TSI3786
2006 International Aerosol Conference, St. Paul, MN, September 10–15, 2006

Mordas, G., Manninen, H.E., and Petaja T. [2008]
“On Operation of the Ultra-fine Water-based CPC TSI3786 and Comparison with other TSI Models (TSI3776, TSI3772, TSI3025, TSI3010, TSI3007).”
Aerosol Science and Technology, **42**, pp. 152-158

Nolan, P.J. and L.W. Pollack [1946]
“The Calibration of a Photoelectric Nucleus Counter”
Proc. Royal Irish Acad., **A9**, pp. 9–31

Nolan, P.J. [1972]
“The Photoelectric Nucleus Counter”
Sci. Proc. Royal Dublin Soc., Series A, Vol. **4**, pp. 161–180

Petäjä, T., Mordas, G., Manninen, H., Aalto, P. P., Hämeri, K., Kulmala, M. [2006]
“Detection Efficiency of a Water-Based TSI Condensation Particle Counter 3785.”
Aerosol Science & Technology, **40(12)**, pp. 1090–1097

Polidori, Andrea; Arhamik, Mohammad; Sioutas, Constantino; Singh, Manisha [2006]
“Indoor and Outdoor Measurements of the Surface Area of Particles Deposited in the Human Lungs Using the TSI Model 3550 Nanoparticle Surface Area Monitor”
2006 International Aerosol Conference, St. Paul, MN, September 10–15, 2006

Pollak, L.W. and A.L. Metnieks [1959]
“New Calibration of Photoelectric Nucleus Counters”
Geofis. Pura Appl., Vol. **43**, pp. 285–301

Quant, F. R., R. Caldow, G.J. Sem, T.J. Addison [1992]
“Performance of Condensation Particle Counters with Three Continuous-Flow Designs,” presented as a poster paper at the European Aerosol Conference, Oxford England, Sept. 7-11, 1992.

Quant, Frederick R.; Oberreit, Derek; Stolzenburg, Mark R. [2004]
“Increasing the Single Particle Counting Range of a Condensation Particle Counter,” Poster
American Association for Aerosol Research 2004 Annual Conference, Atlanta, GA, October 2004

Rich, T.A. [1955]
“A Photoelectric Nucleus Counter with Size Discrimination”
Geofis. Pura Appl., Vol. **31**, pp. 60–65

Rogers, David C.; Herring, Susanne; Stolzenburg, Mark R.; Oberreit, Derek; Quant, Fred [2006]
“Airborne Tests of a New Low-Pressure Water-Based CN Instrument”
2006 International Aerosol Conference, St. Paul, MN, September 10–15, 2006

Scheibel, H.G., and J. Porstendorfer [1983]
“Generation of Monodisperse Ag- and BaCl- Aerosols with Particle Diameters Between 2 and 300 nm. *Journal of Aerosol Science*, **14**, 113-126

Schlichting [1955]
Boundary Layer Theory, 6th ed., McGraw-Hill, New York

- Sem, G.J.
 “Design and Performance Characteristics of Three Continuous-Flow Condensation Particle Counters: a Summary.” *Atmospheric Research* **62**: 267–294, 2002
- Sem, G.J., J.K. Agarwal and C.E. McManus [1980]
 “New Automated Diffusion Battery/Condensation Nucleus Counter Submicron Sizing System: Description and Comparison with an Electrical Aerosol Analyzer”
 Proc. 2nd Symp. Advances in Particulate Sampling and Measurement, U.S. Environ. Protection Agency, Research Triangle Park, North Carolina
- Shi, Qian; Han, Hee-Siew; Kerrigan, Steve W.; Fink, Melissa; Caldow, Rob; Liu, Wei [2006]
 “Particle Number Concentration and Size Distribution Measurements of Ambient Aerosol in Minnesota with New TSI Condensation Particle Counters”
 2006 *International Aerosol Conference*, St. Paul, MN, September 10–15, 2006
- Shi, Q, H.S. Han, S.W. Kerrigan, and E.M. Johnson [2005]
 “Characterization of Two New Butanol-based Condensation Particle Counters.”
 Poster #IPC17, American Association for Aerosol Research annual conference, Austin, Texas, October 2005.
- Shi, Q, H.S. Han, S.W. Kerrigan, and E.M. Johnson [2005]
 “Characterization of A New Butanol-based Ultrafine Condensation Particle Counter,”
 Oral presentation #086 at European Aerosol Conference 2005, Ghent, Belgium.
- Sinclair, D. and G.S. Hoopes [1975]
 “A Continuous Flow Nucleus Counter”
J. Aerosol Sci., Vol. **6**, pp. 1–7
- Stolzenburg, M.R., and P. H. McMurry [1991]
 “An Ultrafine Aerosol Condensation Nucleus Counter.” *Aerosol Science and Technology*, **14**, 48-65, 1991 (TSI paper A82)
- Stolzenburg, M.R. [1988]
 “An Ultrafine Aerosol Size Distribution Measuring System”
 Ph.D. Thesis, University of Minnesota, Minneapolis, Minnesota, July
- Stolzenburg, Mark R.; Iida, Kenjiro; McMurry, Peter H.; Smith, James N.; Keady, Patricia B.; Hering, Susanne, V. [2006]
 “Field Evaluation of a Water-Based Ultrafine Condensation Particle Counter” Poster
 2006 *International Aerosol Conference*, St. Paul, MN
 September 10–15, 2006

Thomas, Rick; Nemitz, Eiko; House, Emily; Hallquist, Mattias; Coe, Hugh [2006]

“Speciated Aerosol Fluxes above an Urban Canopy: Measurements during the GÖTE-2005 Campaign”

2006 International Aerosol Conference, St. Paul, MN,
September 10–15, 2006

Tsang, Hamilton C.; Ma, Roger; Miguel, Antonio H. [2006]

“Number Concentration Measurements Using a Water-Based CPC in Hong Kong Under Heavy Traffic Conditions”

2006 International Aerosol Conference, St. Paul, MN,
September 10–15, 2006

Tuomenoja, Henna; Lamminen, Erkki; Nieminen, Elina; Ukkonen, Ari [2006]

“Real-time Number Size Distribution Measurement, and Density Estimation of Indoor Air Particles Using an ELPI and a CPC”

2006 International Aerosol Conference, St. Paul, MN,
September 10–15, 2006

Westerdahl, Dane; Fruin, Scott; Marshall, Julian; Fine, Phillip M.; Singh, Manisha [2006]

“Coarse, Fine and Ultrafine Particles in Jakarta, Indonesia”

2006 International Aerosol Conference, St. Paul, MN,
September 10–15, 2006

Wu, Yun; Hu, Weiwei; Chalmers, Jeffrey; Wyslouzil, Barbara [2006]

“Electrohydrodynamic Spraying of Lipid Nanoparticles for Drug Delivery”

2006 International Aerosol Conference, St. Paul, MN,
September 10–15, 2006

Zerrath, Axel F.; Bischof, Oliver F. [2005]

“Urban Aerosol in a Light Industrial Area—Particle Size Distribution and Number Concentration Measurements In the Submicron Range”

European Aerosol Conference 2005, Ghent-Belgium,
August 28–September 2, 2005

(This page intentionally left blank)

Index

A

- absolute pressure fault, 9-14
- acknowledgement, 1-2
- additional status screen, 5-4
- aerosol flow
 - check, 9-10
- aerosol gauge pressure, 2-6
- aerosol inlet, 9-11
- Aerosol Instrument Manager[®] software, 8-8, 8-9
- aerosol medium, A-1
- aerosol supply
 - connect, 2-5
- analog input, 8-1
- analog output, 8-1
 - how to set, 5-10
- arrow showing direction of flow on orifice, 9-12

B

- back panel, 4-3

C

- calibration, A-2, C-6, C-7
- circuit boards, 9-6
- coincidence correction, 8-2
- COM port, 8-7
- communications, A-2
- communications parameters, 8-8
- computer interface, 8-2
- condensation nucleation, 1-3
- condenser, 6-3
- conditioner, 9-6
- conditioner temp fault, 9-14
- conditioner temperature, 6-5
- critical control orifice, 9-2
- critical flow, 6-5
- critical flow control orifice replacement, 2-2
- critical total orifice exhaust filter, 9-2
- critical transport flow control orifice replacement, 2-2
- critical transport flow orifice, 9-2

D

- D record, B-7, B-16
- data collection
 - sample time, 8-6
 - set time/date, 5-7
- data fields, 8-6
- data file
 - format, 8-5
- data files, 8-5
- data logging, A-2
- data record example, 8-5
- data records, B-16
- date
 - how to change, 5-7

- day, 8-5
- dead time, 7-2, 7-4
- design, 6-3
- detection efficiency curve, 6-7
- diffusion battery (see references), C-8
- display, 4-1
- display settings
 - how to change, 5-3
- down scan, 9-14

E

- environmental operating conditions, A-1
- ethernet, 8-3
 - telnet client, 8-3

F

- false background counts, A-1
- fans
 - clean, 9-12
- filter noting direction of flow, 9-7
- filter replacement, 2-2
- filters
 - change, 9-7
- firmware commands, 8-9, B-1
 - list, B-1
- flash drive
 - insert, 8-4
- flash drives, 8-4
- flow, A-1
- flow diagram, 1-4
- flow orifices, 9-5
- flow schematic, 9-10
- front panel, 4-1

G

- growth tube, 9-6
- growth tube temp fault, 9-14

H

- help command, 8-9
- heterogeneous condensation, 6-1
- history, 6-2
- home screen, 5-3
- homogeneous condensation, 6-1
- hyperterm, 8-9
- HyperTerminal, 8-8

I-J-K

- indicator light, 4-2
- inlet block removal, 9-8
- inlet flow, 5-5
- inlet jack screw, 9-8
- inlet mode
 - how to change, 5-7

- inlet pressure, 6-5
- inlet pressure fault, 9-14, 9-15
- inlet pressure operation, A-1
- installation, 2-3
- installation equipment, 2-3
- instrument cover
 - remove, 9-2
- interfaces, A-2
- internal clock, 6-6
- internal components, 9-3, 9-4
- internal fans, 9-6

L

- laser fault, 9-14
- laser safety, vii
- live-time counting, 7-2
- low particle concentrations, 7-3
- low water, 9-14

M

- main circuit board, 9-6
- maintenance, 9-1
- maintenance and replacement kits, 9-2
- maintenance kit, 2-2
- maintenance precautions, 9-1
- manual
 - Aerosol Instrument Manager Software for CPC and EAD, xviii
 - Model 3007, xviii
 - Model 3772/3771, xviii
 - Model 3775, xviii
 - Model 3781, xviii
 - Model 3783, xviii
 - Model 3788, xviii
- manual history, iv
- manual organization, xvii
- Model 3787 GP-WCPC
 - flow system, 6-4
 - how it works, 1-3
 - operation, 5-1
 - specifications, A-1
- month, 8-5
- more, 5-6
- moving, 3-1

N

- network
 - how to set up, 5-8
- network address
 - how to change, 5-9
- network gateway
 - how to change, 5-9
- network mask
 - how to change, 5-9
- network set up, 5-6
- nozzle fault, 9-14, 9-15

O

- operating precautions, 5-1
- operation
 - standard procedures, 5-2

- operation procedures, 5-1
- optical detector, 6-3
- optics module, 9-5
- optics temp fault, 9-14
- optics temperature, 6-5
- orifice
 - inspecting, 9-12
- orifices
 - clean/replace, 9-12
- outputs, A-2

P–Q

- packing list, 2-1
- particle concentration accuracy, A-1
- particle concentration calculations, 7-3
- particle concentration range, A-1
- particle counting, 1-3, 7-1
- particle counting efficiency, 6-6
- particle size range, A-1
- power
 - connect, 2-6
- power, A-2
- prescan, 9-14
- product assistance, xviii
- protective caps
 - remove, 2-3
- pulse height, 6-4
- pulse height fault, 9-14
- pulse height low, 9-16
- pulse output, 8-2
- pump, 5-5

R

- R command, B-6
- RAI command, B-2
- RALL command, B-2
- RCT command, B-3
- RD command, B-3
- read command, 8-9, B-1
- read commands, B-1, B-2
- reader's comments (Reader's Comments Sheet) ready, 9-14
- references, C-1
 - diffusion battery, C-8
- related product literature, xviii
- replacement parts, 9-2
- response time, 6-6, 6-7, A-1
- RIE command, B-4
- RIF command, B-4
- RIS command, B-5
- RL command, B-5
- RLL command, B-6
- RPA command, B-6
- RPV command, B-6
- RRD command, B-7
- RRS command, B-8
- RTA command, B-8
- RTC command, B-9
- RTG command, B-9
- RTO command, B-9
- RV command, B-9

S

- S record, B-16
- safety, vii
- safety labels, viii, ix
- sample time, 5-5
 - how to change, 5-6
- sampling options, 2-5
- saturator, 6-3
- scan pause, 9-14
- sensor, 6-3
- separator temp fault, 9-14
- serial port, 8-7
- service, 9-17
- set commands, B-1, B-2, B-10
- set time, 5-5
- setting up, 2-1
- setup screen options, 5-5
- SFC command, B-11
- shipping, 3-1
- shipping, 3-1
- SM command, B-10
- software, A-2
- SP command, B-11
- SR command, B-12
- SSTART command, B-13
- ST command, B-14
- status indicators, 4-2
- status information, 5-4
- status messages, 4-2, 9-14
- status screen, 5-3
- submit comments, xix
- supersaturation, 6-1

T

- technical description, 6-1
- temperature
 - conditioner, conditioner, optics, ambient, 6-5
- temperature control, 6-5
- temperatures out of range, 9-16
- Tera term, 8-8
- terminal emulation software, 8-8
- theory
 - operation, 6-1
- time
 - how to change, 5-7
- time constant, 6-7
- total count accuracy, 7-2
- totalizer, 7-2, 7-4
- totalizer mode, 7-5
- totalizer screen, 5-10
- troubleshooting, 9-15
- tubing
 - inspect, 9-13
- tubing replacement, 2-2

U

- U record, B-17
- unpacking, 2-1, 2-2
- up scan, 9-14
- USB, 8-6

- USB cable
 - connect, 2-6
- USB driver
 - install, 8-6
- user settings
 - how to change, 5-3

V

- vacuum, A-2
 - how to change, 5-6
- vacuum fault, 9-14
- vacuum supply, 9-5

W–X

- warmup, 5-3, 9-14
- warmup process, 2-6
- warning symbols, viii
- water bottle
 - clean, 9-11
- water exhaust port, 6-6
- water removal, 6-6
- water reservoir not filled, 9-16
- water separator, 6-6
- water supply
 - connect, 2-3
- water system, 9-5, A-2
- wick
 - replace, 9-7
- wick assembly, 9-6
- wick cartridge, 9-2, 9-6
 - removing from nozzle assembly, 9-8
 - removing wicks, 9-9
- wicks replacement, 2-2

Y

- year, 8-5

Z

- ZB command, B-14
- ZE command, B-14
- zero check, 5-2
- ZT command, B-15
- ZU command, B-15
- ZV command, B-15

(This page intentionally left blank)

Reader's Comments Sheet

Please help us improve our manuals by completing and returning this questionnaire to the address listed in the "About This Manual" section. Feel free to attach a separate sheet of comments.

Manual Title General Purpose Water-based Condensation Particle Counter Model 3787 P/N 6003713

1. Was the manual easy to understand and use?

Yes No

Please identify any problem area(s) _____

2. Was there any incorrect or missing information? (please explain) _____

3. Please rate the manual according to the following features:

	Good	Adequate	Poor
Readability	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Accuracy	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Completeness (is everything there?)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Organization (finding what you need)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Quality and number of illustrations	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Quality and number of examples	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Comments: _____

4. Which part(s) of this manual did you find most helpful? _____

5. Rate your level of experience with the product:

Beginning Intermediate Expert

6. Please provide us with the following information:

Name _____ Address _____
Title _____
Company _____



UNDERSTANDING, ACCELERATED

TSI Incorporated – Visit our website www.tsi.com for more information.

USA	Tel: +1 800 874 2811	India	Tel: +91 80 67877200
UK	Tel: +44 149 4 459200	China	Tel: +86 10 8251 6588
France	Tel: +33 4 91 11 87 64	Singapore	Tel: +65 6595 6388
Germany	Tel: +49 241 523030		