

# SINGLE-JET ATOMIZER MODEL 9302

---

OWNER'S MANUAL

P/N 1990142, REVISION H  
AUGUST 2015



# START SEEING THE BENEFITS OF REGISTERING TODAY!

---

Thank you for your TSI instrument purchase. Occasionally, TSI releases information on software updates, product enhancements and new products. By registering your instrument, TSI will be able to send this important information to you.

**<http://register.tsi.com>**

As part of the registration process, you will be asked for your comments on TSI products and services. TSI's customer feedback program gives customers like you a way to tell us how we are doing.



UNDERSTANDING, ACCELERATED

**TSI Incorporated** - Visit our website **[www.tsi.com](http://www.tsi.com)** for more information.

<b>USA</b>	<b>Tel:</b> +1 800 874 2811	<b>India</b>	<b>Tel:</b> +91 80 67877200
<b>UK</b>	<b>Tel:</b> +44 149 4 459200	<b>China</b>	<b>Tel:</b> +86 10 8219 7688
<b>France</b>	<b>Tel:</b> +33 1 41 19 21 99	<b>Singapore</b>	<b>Tel:</b> +65 6595 6388
<b>Germany</b>	<b>Tel:</b> +49 241 523030		

©2015 TSI Incorporated

Printed in U.S.A.

# Manual History

The following is a manual history of the Model 9302 Single-Jet Atomizer manual (part number 1990142).

<b>Revision</b>	<b>Date</b>
A	1988
B	May 1989
C	January 1994
D	May 1996
E	August 1999
F	September 2000
G	July 2010
H	August 2015

**Part Number**

1990142 / Revision H / August 2015

**Copyright**

©TSI Incorporated / November 1988–2015 / All rights reserved.

**Address**

TSI Incorporated / 500 Cardigan Road / P.O. Box 64394 / St. Paul, MN 55164 / USA

**Fax No.**

(651) 490-3824

**E-mail Address**

[fluid@tsi.com](mailto:fluid@tsi.com)

**Limitation of Warranty and Liability**

(effective February 2015)

(For country-specific terms and conditions outside of the USA, please visit [www.tsi.com](http://www.tsi.com).)

Seller warrants the goods, excluding software, sold hereunder, under normal use and service as described in the operator's manual, to be free from defects in workmanship and material for **12 months**, or if less, the length of time specified in the operator's manual, from the date of shipment to the customer. This warranty period is inclusive of any statutory warranty. This limited warranty is subject to the following exclusions and exceptions:

- a. Hot-wire or hot-film sensors used with research anemometers, and certain other components when indicated in specifications, are warranted for 90 days from the date of shipment.
- b. Parts repaired or replaced as a result of repair services are warranted to be free from defects in workmanship and material, under normal use, for 90 days from the date of shipment.
- c. Seller does not provide any warranty on finished goods manufactured by others or on any fuses, batteries or other consumable materials. Only the original manufacturer's warranty applies.
- d. This warranty does not cover calibration requirements, and seller warrants only that the instrument or product is properly calibrated at the time of its manufacture. Instruments returned for calibration are not covered by this warranty;
- f. This warranty is **VOID** if the instrument is opened by anyone other than a factory authorized service center with the one exception where requirements set forth in the manual allow an operator to replace consumables or perform recommended cleaning;
- g. This warranty is **VOID** if the product has been misused, neglected, subjected to accidental or intentional damage, or is not properly installed, maintained, or cleaned according to the requirements of the manual. Unless specifically authorized in a separate writing by Seller, Seller makes no warranty with respect to, and shall have no liability in connection with, goods which are incorporated into other products or equipment, or which are modified by any person other than Seller.

The foregoing is **IN LIEU OF** all other warranties and is subject to the **LIMITATIONS** stated herein. **NO OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR PARTICULAR PURPOSE OR MERCHANTABILITY IS MADE. WITH RESPECT TO SELLER'S BREACH OF THE IMPLIED WARRANTY AGAINST INFRINGEMENT, SAID WARRANTY IS LIMITED TO CLAIMS OF DIRECT INFRINGEMENT AND EXCLUDES CLAIMS OF CONTRIBUTORY OR INDUCED INFRINGEMENTS. BUYER'S EXCLUSIVE REMEDY SHALL BE THE RETURN OF THE PURCHASE PRICE DISCOUNTED FOR REASONABLE WEAR AND TEAR OR AT SELLER'S OPTION REPLACEMENT OF THE GOODS WITH NON-INFRINGEMENTS.**

TO THE EXTENT PERMITTED BY LAW, THE EXCLUSIVE REMEDY OF THE USER OR BUYER, AND THE LIMIT OF SELLER'S LIABILITY FOR ANY AND ALL LOSSES, INJURIES, OR DAMAGES CONCERNING THE GOODS (INCLUDING CLAIMS BASED ON CONTRACT, NEGLIGENCE, TORT, STRICT LIABILITY OR OTHERWISE) SHALL BE THE RETURN OF GOODS TO SELLER AND THE REFUND OF THE PURCHASE PRICE, OR, AT THE OPTION OF SELLER, THE REPAIR OR REPLACEMENT OF THE GOODS. IN THE CASE OF SOFTWARE, SELLER WILL REPAIR OR REPLACE DEFECTIVE SOFTWARE OR IF UNABLE TO DO SO, WILL REFUND THE PURCHASE PRICE OF THE SOFTWARE. IN NO EVENT SHALL SELLER BE LIABLE FOR LOST PROFITS, BUSINESS INTERRUPTION, OR ANY SPECIAL, INDIRECT, CONSEQUENTIAL OR INCIDENTAL DAMAGES. SELLER SHALL NOT BE RESPONSIBLE FOR INSTALLATION, DISMANTLING OR REINSTALLATION COSTS OR CHARGES. No Action, regardless of form, may be brought against Seller more than 12 months after a cause of action has accrued. The goods returned under warranty to Seller's factory shall be at Buyer's risk of loss, and will be returned, if at all, at Seller's risk of loss.

Buyer and all users are deemed to have accepted this LIMITATION OF WARRANTY AND LIABILITY, which contains the complete and exclusive limited warranty of Seller. This LIMITATION OF WARRANTY AND LIABILITY may not be amended, modified or its terms waived, except by writing signed by an Officer of Seller.

**Service Policy**

Knowing that inoperative or defective instruments are as detrimental to TSI as they are to our customers, our service policy is designed to give prompt attention to any problems. If any malfunction is discovered, please contact your nearest sales office or representative, or call TSI's Customer Service at 1-800-874-2811 (USA) or (651) 490-2811.

# Contents

<b>Manual History</b> .....	iii
<b>Warranty</b> .....	iv
<b>About This Manual</b> .....	vi
Purpose .....	vi
Getting Help .....	vi
Submitting Comments .....	vi

---

## Sections

<b>Description</b> .....	1
<b>Operation</b> .....	1
Generating Water Droplets .....	2
Generating Salt or Sugar Particles .....	2
Dispersing Polystyrene Latex Particles .....	2
Generating Oil Droplets .....	2
<b>Adjusting the Dilution Air</b> .....	3
<b>Maintenance and Troubleshooting</b> .....	3

# About This Manual

---

## Purpose

This manual describes how to use TSI's Model 9302 Atomizer.

---

## Getting Help

To obtain assistance with this product, or simply to submit suggestions, please contact Customer Service:

TSI Incorporated  
500 Cardigan Road  
Shoreview, MN 55126 USA  
Fax: (651) 490-3824  
Telephone: 1-800-874-2811 (USA) or (651) 490-2811  
E-mail Address: [fluid@tsi.com](mailto:fluid@tsi.com)

---

## Submitting Comments

TSI values your comments and suggestions on this manual. Please use the comment sheet, on the last page of this manual, to send us your opinion on the manual's usability, to suggest specific improvements, or to report any technical errors.

If the comment sheet has already been used, mail or fax your comments on another sheet of paper to:

TSI Incorporated  
500 Cardigan Road  
Shoreview, MN 55126  
Fax: (651) 490-2811  
E-mail address: [fluid@tsi.com](mailto:fluid@tsi.com)

MODEL 9302

# Single-Jet Atomizer

---

## Description

The Model 9302 Single-Jet Atomizer is an aerosol generator specifically designed to align and check out laser velocimeters (LV). A supply of laboratory compressed air is connected directly to the input of its built-in pressure regulator; the pressure gauge shows the air pressure at the output side of the pressure regulator.

In this aerosol generator, the compressed air expands through a small orifice (0.5 millimeter in diameter) in the form of a high-velocity jet located in the jet-nozzle assembly. The jet creates an area of low pressure near the orifice which, in turn, causes the liquid in the reservoir to be sucked up into the orifice. The liquid is then broken into tiny liquid droplets and the compressed air carries the droplets through the outlet tube.

To perform laser velocimeter checkout, direct the atomizer's output tube at the point of beam-crossing. Adjust the height of the output tube by loosening the hex nut and shifting the tube up or down. The Atomizer is designed primarily for LV system checkout and should not be used to feed aerosols into a system under pressure.

---

## Operation

Connect the ¼-inch-diameter (6.35 mm) compressed air hose to your laboratory air supply. Fill the reservoir half-full with the selected liquid. Set the pressure regulator to 25 pounds per square inch (172 kPa). The aerosol output rate is a function of the pressure setting and the atomizer can be operated at any pressure between 5 and 55 pounds per square inch (34 and 379 kPa, respectively). The table below shows the relationship between pressure, as indicated by the pressure gauge, and output rate. Note that the atomizer outlet is open to the atmosphere.

**Relationship Between Input Pressure and Aerosol Output Rate**

Pressure		Aerosol Output
Psi	kPa	L/min
5	34.5	2.4
10	68.9	3.7
15	103	4.7
20	138	5.7
25	172	6.6
35	241	8.3
45	310	10.2
55	379	12.0

The Atomizer may be used to generate aerosols from different materials. Four common applications are described in the following sections.

## Generating Water Droplets

The easiest way to use the Atomizer for laser velocimeter alignment is to fill the liquid reservoir with tap water.

**Note:** *It is normal for some water to drip from the outlet tube; simply collect it.*

The diameter of the water droplet at the outlet depends on the pressure setting—droplet diameter decreases with increased pressure. A setting of 25 pounds per square inch (172 kPa) will yield a number mean diameter of approximately 1.5 micrometers.

## Generating Salt or Sugar Particles

The Atomizer generates solid particles from water-soluble materials such as salt or sugar. Fill the Atomizer's reservoir with an aqueous solution of the desired material. The atomizer will then generate droplets of that solution. Smaller diameter particles of the solute will result if sufficient time is allowed to evaporate the water from the droplets. The resultant particle size depends on the concentration of the solute in the solution.

## Dispersing Polystyrene Latex Particles

A common method of generating monodisperse aerosols is to atomize a hydrosol that contains monodisperse particles.\* For this application, add a drop of monodisperse particles to one liter of distilled water in the reservoir. Such a large dilution is necessary to ensure that each droplet contains only one polystyrene latex particle. The Atomizer output must be mixed with a large volume of dry air. When all the water from these droplets is evaporated, polystyrene latex particles of the original diameter are obtained.

## Generating Oil Droplets

The Atomizer can also generate particles from silicon oil, dioctyl phthalate and various vegetable oils such as corn and peanut oil.



### **C a u t i o n**

The mist of any oil, even that of edible oil, is unhealthy; exhaust it into free air outside the laboratory. The atomizer is not recommended for atomizing suspensions of solid particles such as aluminum oxide, titanium oxide, and silica; they will damage the jet-nozzle assembly.

---

\*A wide size range of monodisperse particles is available from Dow Chemical, 1-800-258-2436.

To generate these particles, fill the Atomizer's reservoir with the selected oil. The diameter of the droplets depends on the setting of the pressure regulator. For a setting of 25 pounds per square inch (172 kPa), the number mean diameter of the particles will be approximately 0.8 micrometer.

---

## Adjusting the Dilution Air

A design change has been made to the Model 9302 Atomizer. Previously, the entire airflow through the Atomizer passed through an orifice nozzle and generated particles. Thus, the full pressure drop was across the nozzle. A rough-adjustment screw has now been added to allow some of the pressure to bleed off as dilution air. (This is useful if the seeding concentration is too high.) Now, a portion of the pressure drop is across the nozzle and the rest of the pressure drop is across an orifice that supplies dilution air to the flow and decreases the concentration of particles out of the larger exit nozzle.

The rough adjustment screw is factory-set to provide no dilution air. To change this setting, follow these steps:

1. Remove the plastic reservoir bowl from the bottom of the Atomizer.
2. Located along the outside diameter of the black aluminum cylinder (attached to the plastic cap) is a no. 10-32 setscrew. Turn it counterclockwise to open the orifice for dilution. Since slight rotation increases the dilution air substantially, withdraw the setscrew slowly. Several adjustments may be necessary before you achieve the correct particle density.

Again, this adjustment is useful only if you want to decrease the particle concentration at the exit of the nozzle. This feature may be useful if you are looking at signals from the flow produced by the Atomizer.

3. To shut off the dilution air flow, turn the setscrew clockwise and tighten firmly.

---

## Maintenance and Troubleshooting

Generally, the Atomizer requires little maintenance. However, should a piece of dirt become trapped in the parts of the jet-nozzle assembly, compressed air may bubble through the assembly's long plastic tube. To correct this minor problem, simply dismantle the assembly and carefully clean each part.



# Reader's Comments

Please help us improve our manuals by completing and returning this questionnaire to the address listed in the "About This Manual" section. Feel free to attach a separate sheet of comments.

**Manual Title** Model 9302 Atomizer

**P/N** 1990142

1. Was the manual easy to understand and use?

Yes       No

Please identify any problem area(s) \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

2. Was there any incorrect or missing information? (please explain) \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

3. Please rate the manual according to the following features:

	<b>Good</b>	<b>Adequate</b>	<b>Poor</b>
Readability	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Accuracy	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Completeness (is everything there?)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Organization (finding what you need)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Quality and number of illustrations	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Quality and number of examples	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Comments: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

4. Which part(s) of this manual did you find most helpful? \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

5. Rate your level of experience with the product:

Beginning       Intermediate       Expert

6. Please provide us with the following information:

Name \_\_\_\_\_ Address \_\_\_\_\_

Title \_\_\_\_\_

Company \_\_\_\_\_





UNDERSTANDING, ACCELERATED

**TSI Incorporated** – Visit our website [www.tsi.com](http://www.tsi.com) for more information.

**USA** Tel: +1 800 874 2811  
**UK** Tel: +44 149 4 459200  
**France** Tel: +33 1 41 19 21 99  
**Germany** Tel: +49 241 523030

**India** Tel: +91 80 67877200  
**China** Tel: +86 10 8219 7688  
**Singapore** Tel: +65 6595 6388

P/N 1990142 Rev. H

©2015 TSI Incorporated

Printed in U.S.A.



**kenelec**  
**scientific**  
measuring up

Distributed by:  
Kenelec Scientific Pty Ltd  
1300 73 22 33  
[sales@kenelec.com.au](mailto:sales@kenelec.com.au)  
[www.kenelec.com.au](http://www.kenelec.com.au)